GARDENLINE

SELF PROPELLED PETROL LAWN MOWER RG-PM 48 S B&S

QUICK START GUIDE

Easy steps to getting started.

- 1. Ensure all items, including your manual are removed from the packaging before discarding.
- 2. Assemble petrol lawn mower as per the instruction manual.
- 3. Ensure that the engine has oil. This petrol lawn mower is supplied with NO OIL in the engine. Please use SAE 30 4 stroke oil.
- 4. Fuel the petrol lawn mower with Unleaded fuel and wait 5 minutes. NOTE: Please ensure that ethanol E10 is not used.
- 5. Adjust choke (3), push primer (12) three times and then pull engine start/stop lever (1) to engage motor. Then pull the starter cable (4). NOTE: Do not pull the drive lever (19) while starting the motor. Pull the drive lever (19) to get the mower moving. Please refer to section 7.1 of the User Guide for more detail.
- 6. Adjust the height of the cutting blades (9).
- 7. Remove all obstacles from lawn.
- 5. Check to ensure that the working environment is safe as prescribed in the instruction manual.
- 6. IF YOU ARE IN ANY DOUBT PLEASE REFER TO THE DETAILED INSTRUCTIONS WITHIN OUR MANUAL.

