G GARDENLINE CLECTRIC HEDGE TRIMMER Quick Set-Up Guide

Using The Hedge Trimmer

Check the warnings in the instruction manual <u>PRIOR TO USE</u> and ensure that you wear the appropriate protection equipment of at least goggles and ear defenders.

- 1. Open carton carefully and remove all items. Ensure you have all items before you discard the packaging.
- 2. Remove the plastic blade guard.
- 3. Mount the supplied finger guard (A) as shown in Fig 1. and secure with the supplied screws (B).



- 4. Connect to the mains supply, as with any outdoor electrical appliance we would always recommend connection via an RCD (Residual current device).
- 5. As a safety feature for this unit to operate, you must hold on the front handle with one hand & operate either of the switches on the rear handle with the other hand.

Important Information To The User!

The Gardenline Hedge Trimmer (GLHT 551) may have VISIBLE FLASHING in the motorhousing when in operation or when the electronic brake is engaging. This is perfectly normal for this product and not a cause for concern or an electric safety hazard.

Warning:

We advise you to run the hedge trimmer continuously for 10 seconds before cutting, as the trimmer has an electrical brake system and should not be used continuously in short bursts. To do so could damage the product and will void the guarantee.



Helpline No. UK/Northern Ireland 0151 6491500 Rep. Ireland 1890 946244 Model Number: 8979