GARDENLINE

GARDEN MULCHER

RLH 2540FB

QUICK START GUIDE

Easy steps to getting started.

- 1. Carefully take all components out of the box (2 people required) and assemble as per the user guide (pages 8 11)
- 2. Push down the safety switch (7) located at the back of the debris box (2) before sliding it through the metal guide rails located underneath the motor unit (1) until you hit the back of the unit.
- 3. Lock the shredded material debris box (2) with safety switch/lever in position by pushing upwards. Refer to page 11 of the user guide.
- 4. IMPORTANT! As a safety precaution, the mulcher WILL NOT START if the safety switch/lever has not been properly engaged.
- 5. Adjust the counter blade to suit the material that needs to be shredded. Refer to page 13 of the user guide for further details. 10

2

- 6. Plug the mulcher into the main power source.
- 7. Press the green button of the ON/OFF switch (10) to switch the mulcher "ON".
- 8. To "STOP" the unit, press the red button of the ON/OFF switch (10).
- NOTE: The mulcher comes with a Forward/ Reverse switch (9) which allows you to reverse the blade to remove any jammed pieces.

10. IF IN DOUBT PLEASE REFER TO THE USER GUIDE PROVIDED.