

## CORDLESS LITHIUM - ION SCREWDRIVER

BT-SD 3.6/Li

## **QUICK START** GUIDE

Easy steps to getting started.

- 1. Read the instruction manual for all SAFETY aspects of using your TAURUS® 3.6V CORDLESS SCREWDRIVER.
- 2. Carefully remove the 3.6V CORDLESS SCREWDRIVER from the packaging, take care that you have all parts supplied in the packaging before discarding.
- 3. Plug the battery charger in the plug socket and connect the charging cable to the charging connection. The red LED on the 3.6V CORDLESS SCREWDRIVER begins to flash. When the charging is completed after 3-5 hours, the red LED goes out.
- 4. Use the slide switch above the ON/OFF switch to select between clockwise and counterclockwise rotation.
- 5. Plug a screw bit on the bit chuck, for detail refer to the manual BT-SD 3.6/Li.
- 6. To Start the 3.6V CORDLESS SCREWDRIVER, push the on/off switch.
- 7. IF IN DOUBT PLEASE REFER TO THE MANUAL PROVIDED.

