

AURUS DIGITAL INVERTER GENERATOR

BT-PG 900

1000W

QUICK START GUIDE

Easy steps to getting started.

- 1. Check the appliance wattage rating you wish to connect to the generator. DO NOT connect if they exceed 900W.
- 2. You must unplug any load from the generator before starting to prevent damage to any appliance.
- 3. Ensure that the engine has oil otherwise it will not start. Please use SAE 30, 4 stroke oil.
- 4. Fuel the generator with Unleaded fuel. **Note: Do not use ethanol blended fuel as this may result in engine failure.**
- 5. It is advisable to properly earth-ground (8) your generator before starting using an earthing cable and (e.g.) an earthing rod. **Note: Cable and earthing rod are not supplied.**
- 6. Move the ventilation switch on the tank cover to the ON position (A).
- 7. Open the petrol cock (3) by turning it horizontal.
- 8. Move the ON/OFF switch (7) to the "I" position.
- 9. Pull the choke lever (16) to position "choke".
- 10. Start the engine with the starter cord (4) by pulling the handle strongly. If the engine does not start, pull the handle again.
- 11. Push the choke lever (16) back approximately 15 to 30 seconds after the engine has started.
- 12. IF IN DOUBT PLEASE REFER TO THE MANUAL PROVIDED.



(16) Choke Lever

print (PMS638C)

size: 151 x 196mm