

GARDENLINE®

CORDLESS HEDGE TRIMMER

GL-CH 36 Li

QUICK START GUIDE

Easy steps to getting started.

1. Ensure all items, including your manual are removed from the packaging before discarding.
2. Ensure the battery is charged. Refer to Section 6 in the instruction manual for further detail on the charging process.
3. To start the hedge trimmer, press the On/Off switch (6) on the steady grip with one hand and the safety switch (4) on the additional handle with the other hand.
4. For practical advise on how to use the hedge trimmer, please refer to Section 7 of the instruction manual.
- 5. IF YOU ARE IN ANY DOUBT PLEASE REFER TO THE DETAILED INSTRUCTIONS WITHIN OUR MANUAL**

