

GARDEN FOUNTAIN PUMP

GLSP 57

QUICK START GUIDE

Easy steps to getting started.

- 1. Ensure all items, including your user guide are removed from the packaging before discarding.
- 2. Choose one of the three operation options:
 - Fountain only
 - Fountain together with water spout connection
 - Water spout connection only
- 3. Fountain only: Turn the stopcock (Fig. 2/Item A) of the spout connection one quarter turn clockwise to close it. Open the stopcock (Fig. 2/Item B) of the fountain connection. Connect the connection pipe (Fig. 1b/ Item 8) to the joining piece (Fig. 1b/ Item 9). Attach one of the provided fountain spouts (Fig. 1b/ Item 5, 6 or 7) to the connecting pipe (Fig. 1b/ Item 9).
- 4. Fountain together with water spout connection: Install one of the fountain spouts as described above in point 3. In addition attach water spectacles with a hose inner diameter of approx. 12 mm or 19 mm to the water spout connection and open the spout connection by turning the stopcock (Fig. 2/Item A) counter clockwise.
- 5. Water spout connection only: Close the fountain connection by turning the stopcock (Fig. 2/Item B) one quarter clockwise. Make sure that the stopcock of the spout connection (Fig. 2/Item A) is open.
- 6. Place the pond filter on a horizontal surface, located higher than the pond bed. **Important!** The pond filter is not allowed to be operated outside of the water. Furthermore, the equipment is not designed for use in swimming pools and paddling pools of any kind or other bodies of water in which people or animals may be present during operation.
- 7. When installing the pond filter in the pond, ensure that the fountain head sticks out of the water surface.
- 8. Clean the filter whenever the delivery head or delivery rate diminishes. Refer to Section 7 in the user guide for further information.
- 9. Clean the rotating parts of the pump at regular intervals if you use water that contains lime. Refer to Section 7 in the user guide for further information.
- 10. IF YOU ARE IN ANY DOUBT PLEASE REFER TO THE DETAILED INSTRUCTIONS WITHIN OUR USER GUIDE.







print (PMS376C) print (PMS3425C)