



2400w Electric Impact Shredder

Quick Set-Up Guide

Using the Electric Impact Shredder

Easy Steps to getting Started

- 1 **Unpack the Impact Garden Shredder:**
 - a) Open carton carefully and remove all items.
 - b) Ensure you have all items before you discard the packaging.
- 2 **Assemble unit:**
 Place the motor housing (8) upside down on the floor & insert the chassis (5) into the provided openings as far as it will go. Secure the chassis using the screws (item 16) and the washers (item 17).

 Remove the sleeves (19), nuts (21) and washers (20) from the axle (7) and push it through the holes in the chassis (5). Replace the washer and the sleeve followed by the wheel (12) and then tighten the nut to fix. Place the wheel cap (13) to finish the job.

 To fix the plunger holder (10) simply push it onto the desired place on the chassis.
- 3 **Now you are ready to use the unit please check the cable is securely connected to the unit.**

 Please remember max size of branches is 40 mm.


 The Cutter blade setting is pre-set at the factory and should not need any initial adjustment.



IMPORTANT!

Please read the safety warnings and instructions in the user manual before operating this appliance.

Fig. 2



Helpline No. UK / Northern Ireland 0151 649 1500
 Rep. Ireland 1890 946244
 Model Number: GLEKS 2440 / PLU: 66926 / On-sale date: 08.2015