



Einhell

EXPERT Plus

POWER X CHANGE

GE-LC 18 LI T Kit

CI Pole-Mounted Powered Pruner

Item No.: 3410815

Ident No.: 11014

Bar Code: 4006825604320

The cordless pole pruner GE-LC 18 Li T Kit is a powerful device which makes it possible to cut branches aloft effortlessly and independently from the power supply from the ground. Due to its new Einhell Power X-Change battery system, the pruner has an 18 V battery with 3.0 Ah, which can be used for each further device from the Power X-Change family, for larger works. Thereby, the metal gearbox provides a long duration, and the OREGON-quality blade and the OREGON-chain care for clean cutting results. By means of its various setting options, the pole pruner can be adjusted to each working situation. The automatic chain lubrication and the chain exchange without tools allow a simple handling.

Features

- Battery system - Power X-Change
- Battery capacity control with 3 LEDs
- Battery can be used for other Power-X-Change products
- System high-speed charger included
- 90° pivotable attachment for effortless horizontal cuts
- Motor head tiltable by 7 settings
- Main handle tiltable by 4 settings
- Continuously adjustable telescopic aluminium handle (880-1820 mm)
- Additional adjustable handle with quick fastener
- OREGON quality blade and chain
- Toolless chain tensioning and chain change
- Metal gearing for a long life
- Oil tank for automatic chain lubrication
- Claw stop
- Chain catch bolt

Technical Data

- Accumulator	18 V 3000 mAh Li-Ion
- Max. running time	60 min
- Charging time	1h
- Sword length	200 mm
- Cutting length	170 mm
- Cutting speed	3.76 m/s
- Length of telescope bar	183 - 277 cm
- Number of accumulators	1 Pieces

Logistic Data

- Product weight	4.6 kg
- Gross weight single packaging	6.2 kg
- Dimensions single packaging	205 x 122 x 1215 mm
- Pieces per export carton	3 Pieces
- Gross weight export carton	20 kg
- Dimensions export carton	1230 x 370 x 245 mm
- Container quantity (20"/40"/40"HC)	750 1551 1701



Available as special accessories



18V 5,2 Ah Power-X-Change
Battery
Item No.: 4511357
Bar Code: 4006825598865
Einhell Accessory



18V 30min Power-X-Change
Power Tools Accessory
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 1,5 Ah Power-X-Change
Battery
Item No.: 4511340
Bar Code: 4006825590586
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



Ersatzschwert GC-EC 750 T
Chain Saw Accessory
Item No.: 4500168
Bar Code: 4006825606348
Einhell Grey



Ersatzkette GC-EC 750 T
Chain Saw Accessory
Item No.: 4500188
Bar Code: 4006825606355
Einhell Grey



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory