

Item No.: 3410473

Ident No.: 11016

Bar Code: 4006825616477

The GC-CG 7.2 Li cordless grass and shrub shear is a high-quality and practical tool which makes easy work of trimming lawn edges, bushes and shrubs. The safety switch on the handle can be comfortably operated with one hand and prevents the tool from being switched on unintentionally.

## Features

- Safety switch

- Grass cutting blade
- Shrub shears blade
- Blade change without tools

**Einhell Germany AG** 

- Laser-cut blade
- Ergonomic handle
- 2 hours charger

## Technical Data

- Max. running time	80 min
- Charging time	2h
- Cutting width with grass shear knife	90 mm
- Cutting width with shrub cutting knife	130 mm
- Cutting thickness with shrub cutting	8 mm
knife	
- Spacing between teeth of shrub cutting	14 mm
knife	
- Accumulator	7.2 V   1500 m

- Number of accumulators

7.2 V | 1500 mAh | Li-Ion 1 Pieces

305 x 110 x 130 mm

440 x 320 x 260 mm

5440 | 11200 | 12600

0.7

1.1 kg

8 Pieces 12 kg

## Logistic Data

- Product weight

- Gross weight single packaging
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)







