



TE-CD 18/3 Li; EX; CH

Cordless Drill Kit

Item No.: 4513725

Ident No.: 11016

Bar Code: 4006825625004

Features

- Member of the Power X-Change family
- 2-speed gearing for powerful screwing and fast drilling
- Single-sleeve chuck with quick-stop
- Automatic spindle lock for easy tool change
- Overload slip coupling prevents over-turning of screws
- Ergonomic soft grip for comfortable operation
- Incl. LED to illuminate the work area
- Incl. practical belt clip
- Incl. 2 x 2,0 Ah rechargeable batteries and high-speed charger
- Delivered in a practical case

Technical Data

- DC voltage	18 V
- Accumulator	18 V 2000 mAh Li-Ion
- Charging time	40min
- Number of gears	2
- Idle speed (gear 1)	0-350 min ⁻¹
- Idle speed (gear 2)	0-1250 min ⁻¹
- Max. torque hard joint	40 Nm
- Number of torque steps	19 settings
- Drill chuck	13 mm single sleeve
- Number of accumulators	2 Pieces

Logistic Data

- Product weight	1.39 kg
- Gross weight single packaging	4.08 kg
- Dimensions single packaging	330 x 100 x 333 mm
- Pieces per export carton	5 Pieces
- Gross weight export carton	20.4 kg
- Dimensions export carton	540 x 345 x 355 mm
- Container quantity (20"/40"/40"HC)	2065 4275 5015



Available as special accessories

	Bit-Set, 23-teilig Cordless Drill Accessory Item No.: 4258073 Bar Code: 4006825573268 Einhell Grey		Drill and bit set, 70 pcs Power Tools Accessory Item No.: 4258085 Bar Code: 4006825563610 Einhell Grey
	18V 5,2 Ah Power-X-Change Battery Item No.: 4511357 Bar Code: 4006825598865 Einhell Accessory		18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350 Einhell Accessory
	18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory		18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory
	18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory		18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory
	18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory		18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory
	18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 Einhell Accessory		18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory
	18V 30min Power-X-Change PXC-Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory		