



TE-CD 18/3 Li-i; EX; CH

Cordless Impact Drill

Item No.: 4513727

Ident No.: 11016

Bar Code: 4006825625011

Features

- Member of the Power X-Change family
- Li-ion battery: no self-discharging, small, light, easy to handle
- 3 functions: screwdriving, drilling, impact drilling in masonry
- 2-speed gearing for powerful screwdriving and fast drilling
- High-quality 13 mm quick-change drill chuck made of metal
- Quick-stop function
- Including LED lamp to illuminate the work area
- Incl. 1 x 3,0 Ah rechargeable battery and high-speed charger
- Practical storage and carrying bag

Technical Data

- Accumulator	18 V 3000 mAh Li-Ion
- Charging time	1h
- Number of gears	2
- Idle speed (gear 1)	0-350 min ⁻¹
- Idle speed (gear 2)	0-1250 min ⁻¹
- Max. torque hard	40 Nm
- Number of torque steps	20 settings
- Drill chuck	13 mm single sleeve
- Drilling capacity in concrete	8 mm
- Impact rate (gear 1)	0-5250 min ⁻¹
- Impact rate (gear 2)	0-18750 min ⁻¹
- Number of accumulators	1 Pieces

Logistic Data

- Product weight	1.49 kg
- Gross weight single packaging	3.78 kg
- Dimensions single packaging	100 x 333 x 330 mm
- Pieces per export carton	5 Pieces
- Gross weight export carton	18.9 kg
- Dimensions export carton	540 x 345 x 355 mm
- Container quantity (20"/40"/40"HC)	2065 4275 5015



Available as special accessories

	Bit-Set, 23-teilig Cordless Drill Accessory Item No.: 4258073 Bar Code: 4006825573268 Einhell Grey		Drill and bit set, 70 pcs Power Tools Accessory Item No.: 4258085 Bar Code: 4006825563610 Einhell Grey
	18V 5,2 Ah Power-X-Change Battery Item No.: 4511357 Bar Code: 4006825598865 Einhell Accessory		18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350 Einhell Accessory
	18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory		18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory
	18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory		18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory
	18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory		18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory
	18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 Einhell Accessory		18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory
	18V 30min Power-X-Change PXC-Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory		