G

E

Service information

We have competent service partners in all countries named on the guarantee certificate whose contact details can also be found on the guarantee certificate. These partners will help you with all service requests such as repairs, spare and wearing part orders or the purchase of consumables. Please note that the following parts of this product are subject to normal or natural wear and that the following parts are therefore also required for use as consumables.

Category	Example
Wear parts*	Carbon brushes
Consumables*	
Missing parts	

* Not necessarily included in the scope of delivery!

In the effect of defects or faults, please register the problem on the internet at www.isc-gmbh.info. Please ensure that you provide a precise description of the problem and answer the following questions in all cases:

- Did the equipment work at all or was it defective from the beginning?
- Did you notice anything (symptom or defect) prior to the failure?
- What malfunction does the equipment have in your opinion (main symptom)? Describe this malfunction.

Declaration of confirmity

ISC GmbH · Eschenstraße 6 · D-94405 Landau/Isar

explains the following conformity according to EU directives and norms for the following product

Cordless Blower PXCBLK-018U / Fast Charger PXCG-030U (Ozito)				
□ 2014/29/EU □ 2005/32/EC_2009/125/EC □ 2014/35/EU □ 2006/28/EC ※ 2014/30/EU □ 2014/32/EU □ 2014/53/EC □ 2014/68/EU □ 90/396/EC_2009/142/EC □ 89/686/EC_96/58/EC ※ 2011/65/EU	 X 2006/42/EC Annex IV			
Standard references: EN 60745-1; EN 15503; EN 62233; EN 55014-1; EN 55014-2; EN 61000-3-2; EN 61000-3-3				
Landau/Isar, den 18.05.2016	Weichselgartner/Geneval-Manager Gao/Product-Management			

First CE: 16 Art.-No.: 34.335.19 I.-No.: 11016 Subject to change without notice Archive-File/Record: NAPR014260 Documents registrar: R. Gehard Wiesenweg 22, D-94405 Landau/Isar











GB Additonal operating & safety instructions Cordless Blower





Danger! - Read the operating instructions to reduce the risk of inquiry.



Caution! Do not use the tool in rain or snow. Do not expose the tool to wet conditions.



Caution! Keep all other persons away from the danger zone.

Caution! Wear goggles and ear muffs.



Caution! Safety class III / Safety extra-low voltage.

The reprinting or reproduction by any other means, in whole or in part, of documentation and papers accompanying products is permitted only with the express consent of the iSC GmbH.

Subject to technical changes

Items supplied

Please check that the article is complete as specified in the scope of delivery. If parts are missing, please contact our service center or the sales outlet where you made your purchase at the latest within 5 working days after purchasing the product and upon presentation of a valid bill of purchase. Also, refer to the warranty table in the service information at the end of the operating instructions.

- Open the packaging and take out the equipment with care.
- Remove the packaging material and any packaging and/or transportation braces (if available).
- Check to see if all items are supplied.
- Inspect the equipment and accessories for transport damage.
- If possible, please keep the packaging until the end of the guarantee period.

Danger!

The equipment and packaging material are not toys. Do not let children play with plastic bags, foils or small parts. There is a danger of swallowing or suffocating!

Proper use

The cordless leaf blower is designed to handle only foliage and garden refuse such as grass and small branches. Any other use is prohibited.

The equipment is to be used only for its prescribed purpose. Any other use is deemed to be a case of misuse. The user / operator and not the manufacturer will be liable for any damage or injuries of any kind caused as a result of this.

Please note that our equipment has not been designed for use in commercial, trade or industrial applications. Our warranty will be voided if the machine is used in commercial. trade or industrial businesses or for equivalent purposes.

Technical data

Idle speed n _o	12.000/min
Air speed	
Max. operating time	. approx. 10 min
Protection class:	
L _{wa} sound power level	79,5 dB
L _{pA} sound pressure level	
K uncertainty	
Vibration ahv	≤ 2.5 m/s²
K uncertainty	1.5 m/s²

The machine may exceed 85 dB (A). The operator will require noise protection measures if this is the case.

The specified vibration value was established in accordance with a standardized testing method. It may change according to how the electric equipment is used and may exceed the specified value in exceptional circumstances.

The specified vibration value can be used to compare the equipment with other electric power tools.

The specified vibration value can be used for initial assessment of a harmful effect.

Keep the noise emissions and vibrations to a minimum.

- Only use appliances which are in perfect working order.
- Service and clean the appliance regularly.
- Adapt your working style to suit the appliance.
- Do not overload the appliance.
- Have the appliance serviced whenever necessary.
- Switch the appliance off when it is not in use.
- Wear protective gloves.

Caution! Residual risks

Even if you use this electric power tool in accordance with instructions, certain residual risks cannot be rules out. The following hazards may arise in connection with the equip-

ment's construction and lavout:

- 1. Lung damage if no suitable protective dust mask is used.
- 2. Damage to hearing if no suitable ear protection is used.
- 3. Health damage caused by hand-arm vibrations if the equipment is used over a prolonged period or is not properly guided and maintained.



For EU countries only

Never place any electric power tools in your household refuse.

To comply with European Directive 2012/19/EC concerning old electric and electronic equipment and its implementation in national laws, old electric power tools have to be separated from other waste and disposed of in an environment-friendly fashion, e.g. by taking to a recycling depot.

Recycling alternative to the return request: As an alternative to returning the equipment to the manufacturer, the owner of the electrical equipment must make sure that the equipment is properly disposed of if he no longer wants to keep the equipment. The old equipment can be returned to a suitable collection point that will dispose of the equipment in accordance with the national recycling and waste disposal regulations. This does not apply to any accessories or aids without electrical components supplied with the old equipment.

This consignment contains lithium-ion batteries. In accordance with special provision 188 this consignment is not subject to the ADR regulations. Handle with care. Danger of ignition in case of damage to the consignment package. If the consignment package is damaged: Check and if necessary repackage. For further information contact: 0049 1807 10 20 20 66 (fixed network 14 ct/min, mobile phone max. 42 ct/min) Outside Germany charges will apply instead for a regular call to a landline number in Germany.

Charger indicator / Fast Charger

Indicator status			
Red LED	Green LED	Explanations and actions	
Off	Flashing	Ready for use The charger is connected to the mains and is ready for use; there is no battery pack in the charger	
On	Off	Charging The charger is charging the battery pack in quick charge mode.	
Off	On	The battery is 85%-100% charged and ready for use. (Charging time for 1.5 Ah battery: 30 min) (Charging time for 2.0 Ah battery: 40 min) (Charging time for 3.0 Ah battery: 60 min) (Charging time for 4.0 Ah battery: 80 min) (Charging time for 5.2 Ah battery: 105 min) Action: Take the battery pack out of the charger. Disconnect the charger from the mains supply.	
Flashing	Off	Adapted chargingThe charger is in gentle charging mode.For safety reasons the charging is performed less quickly and takesmore than 1 hour. The reasons can be:- The battery pack has not been used for a very long time or an alreadyflat battery was further discharged (exhaustive discharge) The battery pack temperature is outside the ideal range (between 25°C and 45° C).Action:Wait for the charging to be completed; you can still continue to chargethe battery pack.	
Flashing	Flashing	FaultCharging is no longer possible. The battery pack is defective.Action:Never charge a defective battery pack.Take the battery pack out of the charger.	
On	On	Temperature faultThe battery pack is too hot (e.g. due to direct sunshine) or too cold(below 0° C).Action:Remove the battery pack and keep it at room temperature (approx. 20°C) for one day .	