

Cordless Grass- and shrub shear AGS 18 S

Art.-No.: **34.105.90**

Bar code: **4006825341386**

Sales unit: **4 pcs**

A combination unit of cordless grass shear and shrubs shear. Edges and corner on your lawn pose no longer a problem. The integrated and powerful power pack makes you independent of power supply. After using the grass shear also the guide part can be stowed in the wall mounting certainly and the Akku's can be reloaded. Two in the wall mounted integrated LED's give information about the loading condition of the Akku's during the loading process. The safety switch blocks an unintended start of the unit.

The attachable telescopic handle makes it possible to work in an upright position. A safety switch is also integrated in the handle grip itself.

Features:

- Safety switch (1)
- Wall mounting bracket with integrated charger (2)
- Castors for easy guidance (3)
- Telescopic handle (4)
- Grass cutting blade (5)
- Shrub cutting shear (6)

Technical data:

- Battery pack: 18 Volt / 1500 mAh
- Charging time: 7-9 h
- Operating time: max. 120 min.
- Cutting width with grass cutting blade: 85 mm
- Cutting width with shrub cutting shear: 160 mm
- teeth space of shrub cutting shear: 8 mm
- Weight: 3 kg
- Packing dimensions: 690 x 150 x 160 mm

