







Cordless Scarifier / Aerator

GC-SC 36/31 Li-Solo

Item No.: 3420660

Ident No.: 11018

Bar Code: 4006825636956

The Einhell Cordless Scarifier GC-SC 36/31 Li-Solo is a professional lawn care tool. It is recommended for lawns up to 300 m2. As a member of the Power X-Change family, the batteries fit all products in this range. Two 18 V batteries power the series-wound motor. The eight double blades are mounted on the ball bearing-mounted blade cylinder, which is made of sturdy stainless steel. The working depth can be adjusted to three levels and to a transport position. The handle is height-adjustable and foldable. The large wheels protect the lawn, and the housing is made of impact-resistant plastic. The GC-SC 36/31 Li can be optionally upgraded to a 3-in-1 combination tool (aerator shaft/collection basket). Supplied without batteries or a charger.

Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Powerful series motor
- Ball-bearing scarifier drum with 8 stainless steel double-knives.
- Scarifying depth adjustment, 3 levels + transport position
- Foldable and height adjustable guide rail.
- Wide wheels exert less stress on the lawn
- Impact-resistant plastic housing
- Recommended for lawn areas up to 300 m² (depending on batteries)
- Supplied without battery and charger (available separately)
- Optional extensible with aerator roller and catch bag

Technical Data

Working width 31 cm
Number of knives 8 Pieces
Wheel diameter front 18 cm
Wheel diameter rear 10 cm

Logistic Data

- Tool weight 10 kg- Gross Weight 12 kg

- Dimensions single packaging 600 x 460 x 330 mm

- Pieces per export carton- Gross weight of export carton1 Pieces12 kg

Dimensions export carton
Container quantity (20"/40"/40"HC)
320 | 670 | 765





















Available as special accessories



Einhell Accessory

Fangsack GC-ES/SA 1231/1 Scarifier Accessory Item No.: 3405577 Bar Code: 4006825629699

Einhell Accessory

18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 **Einhell Accessory**

18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 Einhell Accessory

18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory

Power-X-Twincharger 3 A Charger Item No.: 4512069 Bar Code: 4006825629729

Einhell Accessory

Messerwalze GC-ES/SA 1231/1 Scarifier Accessory Item No.: 3405582 Bar Code: 4006825629682 Einhell Accessory

18V 4,0 Ah Power-X-Change Battery Item No.: 4511396

Bar Code: 4006825610376 Einhell Accessory

18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704

Einhell Accessory

18V 30min Power-X-Change Charger Item No.: 4512011

Bar Code: 4006825587029 Einhell Accessory

Power-X-Boostcharger 6 A Charger

Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



