



Einhell

CLASSIC

POWER X-CHANGE

Cordl. Wet/Dry Vacuum Cleaner

TC-VC 18/20 Li S-Solo

Item No.: 2347130

Ident No.: 11027

Bar Code: 4006825625998

The Einhell TC-VC 18/20 Li S-Solo wet & dry vac is a member of the Power X-Change series. All the rechargeable batteries & chargers in the system can be used with every product in the series. This product comes without a battery or charger. The rust-free, sturdy stainless steel tank has a capacity of 20 l, and a paper dirt bag, pleated & foam filter is also included. For easy maneuverability it has four castors, and a holder for accessories and practical blow connection are also built in. The product also comes with a large suction nozzle with combination insert for carpets and smooth floors, a special crevice nozzle and an upholstery nozzle, a plastic hose and a 3-part extension tube with 36 mm diameter.

Features & Benefits


- 20 l stainless steel tank, rust-proof and sturdy
- Blow connection for blow-cleaning of hard-to-reach areas
- 4 castors for good mobility
- Practical accessories holder for clean stowage and operations
- 36 mm hose system maintains high air and dirt flow
- Member of Power X-Change family - one battery for all products
- Complete with plastic suction hose and three-part extension tube
- Large suction nozzle for carpets and floors for top performance
- Crevice nozzle for narrow areas & upholstery nozzle for car seats
- Incl. pleated filter, paper dirt bag and foam filter

Technical Data

- Volume	20 L
- Suction power max.	80 mbar
- Suction hose length	1.5 m
- Suction hose diameter	36 mm
- Sound pressure level Lpa	72 dB (A)

Logistic Data

- Gross weight (kg)	5.62
- Pieces per export carton	1 Pieces
- Container quantity (20"/40"/40"HC)	476 980 1120



Available as special accessories



Pleated Filter With Lid
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351113
Bar Code: 4006825566512
Einhell Accessory



Fabric Filter
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351140
Bar Code: 4006825231151
Einhell Accessory



Extension hose 36mm/3m
Wet/Dry Vacuum Cleaner Access.
Item No.: 2362000
Bar Code: 4006825543018
Einhell Accessory

Dirt Bag Filter 20l (5 pcs.)
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351152
Bar Code: 4006825236040
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 30min Power X-Change
Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



Synthetic dust bag 25L(5 pcs)
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351190
Bar Code: 4006825625684
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Round Carpet Brush
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351230
Bar Code: 4006825630091
Einhell Accessory



Soft Upholstery Brush
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351225
Bar Code: 4006825630084
Einhell Accessory



Set Of Nozzles 1
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351235
Bar Code: 4006825630107
Einhell Accessory



Car Cleaning Set
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351245
Bar Code: 4006825630121
Einhell Accessory



Long Crevice Nozzle
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351205
Bar Code: 4006825630046
Einhell Accessory



Small Universal Nozzle
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351210
Bar Code: 4006825630053
Einhell Accessory



Universal Floor Nozzle
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351215
Bar Code: 4006825630060
Einhell Accessory



Hard Upholstery Brush
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351220
Bar Code: 4006825630077
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Power-X-Boostcharger 6 A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



Power-X-Twincharger 3 A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Set Of Nozzles 2
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351255
Bar Code: 4006825635676
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 1,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512021
Bar Code: 4006825601350
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory