







Cordless Orbital Sander

TC-OS 18/187 Li Solo

Item No.: 4460725

Ident No.: 11018

Bar Code: 4006825642735

The Einhell TC-OS 18/187 Li Solo cordless orbital sander is a light and handy orbital sander from the PXC family, with all the advantages of the flexible, completely interchangeable system series. The orbital sander is ideally suited for grinding/sanding flat surfaces. Thanks to the micro hoop-andloop fastening and clamping device, changing the abrasive paper is quick and easy, but sheets of abrasive paper without hoop-and-loop fastening can also be clamped. For comfortable handling it has large grip surfaces with soft grips. For a clean workplace there is a dust bag and an adapter for a vacuum cleaner included. The product is supplied complete with one sheet of abrasive paper. Supplied without a rechargeable battery or charger.

Features & Benefits

- Member of the Power X-Change family
- Light, handy orbital sander
- Ideally suited for sanding flat surfaces
- Easy abrasive paper change using micro hook-and-loop fastening
- Also suitable for abrasive paper without hook-and-loop fastening
- Comfortable to handle thanks to large grip areas and soft grip
- Dust bag collects dust from sanding
- Suitable for connecting to an external dust extractor
- Incl. 1 sheet of abrasive paper so you can get started right away
- Supplied without battery and charger (available separately)

Technical Data

- Oscillating speed 24000 min^-1 - Oscillating circuit 2 mm - Sanding area 187 x 97 mm - Sandpaper size hook and loop 187 x 97 mm

connection

- Sandpaper size clamp-connection 237 x 97 mm

Logistic Data

- Product weight (kg) 1.166 1.589 - Gross weight (kg)

- Dimensions single packaging 225 x 161 x 111 mm

- Pieces per export carton 8 Pieces - Gross weight of export carton 12.8 kg

- Dimensions export carton 450 x 285 x 330 mm - Container quantities (20"|40"|40"HC) 5600 | 11480 | 13120

















Available as special accessories



18V 30min Power X-Change

Charger Item No.: 4512011

Bar Code: 4006825587029

Einhell Accessory



Power-X-Twincharger 3 A

Charger Item No.: 4512069

Bar Code: 4006825629729

Einhell Accessory



18V 4,0 Ah Power-X-Change

Battery

Item No.: 4511396

Bar Code: 4006825610376

Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042

Bar Code: 4006825613704 Einhell Accessory



Power-X-Boostcharger 6 A

Charger Item No.: 4512064

Bar Code: 4006825629019

Einhell Accessory



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698

Einhell Accessory



18V 5,2 Ah P-X-C Plus

Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory

Battery-Running-Times

running time (in min.)

Usage	running time	
Unit of measure	min.	
1.5 Ah PXC	25	
2.0 Ah PXC	34	
2.5 Ah PXC	42	
2.6 Ah PXC+	44	
3.0 Ah PXC	50	
3.0 Ah PXC+	50	
4.0 Ah PXC	67	
5.2 Ah PXC+	87	
4-6 Ah PXC+ (4.0 Ah)	67	
4-6 Ah PXC+ (6.0 Ah)	100	