





Cordless Orbital Sander

TE-OS 18/230 Li Solo

Item No.: 4460720 Ident No.: 11018 Bar Code: 4006825642728

The Einhell TE-OS 18/230 Li Solo cordless orbital sander is a member of the flexible PXC series from Einhell. The robust, powerful orbital sander with an aluminium baseplate is ideally suited for sanding flat surfaces. Electronic speed control ensures that the tool can be adjusted to each particular material. The abrasive paper can be changed easily thanks to the micro hook and loop fastening, and abrasive paper without hook and loop fastening can also be used. For a firm hold the grip surfaces have a soft grip. A dust bag collects dust from sanding and a vacuum cleaner can also be connected. Complete with 3 sheets of abrasive paper so you can get started right away, but without a battery or charger.

Features & Benefits

- Member of the Power X-Change family
- Rugged, powerful orbital sander
- Ideally suited for sanding flat surfaces
- Speed electronics for material-compatible operation
- Easy abrasive paper change using micro hook-and-loop fastening
- Also suitable for abrasive paper without hook-and-loop fastening
- Rugged, durable aluminum base plate
- Ergonomic grip areas with softgrip
- Dust bag collects dust from sanding
- Vacuum cleaner can be attached to keep the work area really clean
- 3x sheets of abrasive paper so you can get started right away
- Supplied without battery and charger (available separately)

Technical Data

 Oscillating speed 	14000-22000 min^-1
- Oscillating circuit	2.5 mm
- Sanding area	230x115 mm
- Sandpaper size hook and loop	230 x 115 mm
connection	
- Sandpaper size clamp-connection	280 x 115 mm


Logistic Data

- Product weight (kg)	1.53
- Gross weight (kg)	1.859
- Dimensions single packaging	285 x 141 x 179 mm
- Pieces per export carton	8 Pieces
- Gross weight of export carton	16.6 kg
- Dimensions export carton	540 x 310 x 370 mm
- Container quantities (20" 40" 40"HC)	3456 7296 8512









Available as special accessories



18V 30min Power X-Change Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory

Power-X-Twincharger 3 A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory







Power-X-Boostcharger 6 A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory

18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory

18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory

18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory

Battery-Running-Times

running time (in min.)

Usage	running time	
Unit of measure	min.	
1.5 Ah PXC	20	
2.0 Ah PXC	27	
2.5 Ah PXC	33	
2.6 Ah PXC+	35	
3.0 Ah PXC	40	
3.0 Ah PXC+	40	
4.0 Ah PXC	54	
5.2 Ah PXC+	70	
4-6 Ah PXC+ (4.0 Ah)	54	
4-6 Ah PXC+ (6.0 Ah)	80	