







TE-CS 18/165-1 Li - Solo

Item No.: 4331207

Ident No.: 11019

Bar Code: 4006825647556

WER CHANGE

The Einhell cordless TE-CS 18/165-1 Li-Solo handheld circular saw is compact, light and easy to work with, and it is a member of the Einhell Power X-Change family. The high-performance lithium-ion batteries are used in all Power X-Change products. You can adjust the cutting depth and tilt angle on the hand-held circular saw without any tools. A spindle lock makes it easy to swap sawblades with a 20 mm bore. High-quality LEDs and a dust vacuum attachment give you a clear view of what you are doing and keep the work area clean. The TE-CS 18/165-1 Li-Solo is compatible with the Einhell guide rail which is available separately. The saw is supplied without a battery and charger which are available separately.

Features & Benefits

- A member of the Power X-Change family
- Small, light and handy for comfortable operation
- Easy adjustment without tools (cutting depth, tilt angle)
- Dust extractor adapter to keep the workplace clean
- Compatible with the Einhell guide rail
- Easy changing of the saw blade thanks to the spindle lock
- High quality aluminium base plate
- Sawblades with 20mm core can be used
- High quality sawblade is included in delivery
- High-quality LED for optimum illumination of the cutting area
- Supplied without battery and charger (available separately)

Technical Data

- Accumulator 0 mAh - No-load speed 4200 min^-1 Ø165 x Ø20 mm - Saw Blade - Number of saw teeth 18 Pieces - Cutting depth at 90° 54 mm - Cutting depth at 45° 35 mm - Number of accumulators 0 Pieces

Logistic Data

- Product weight 2.6 kg - Gross weight single packaging 3.342 kg

315 x 200 x 285 mm - Dimensions single packaging

- Pieces per export carton 2 Pieces - Gross weight export carton 7.91 kg

- Dimensions export carton 420 x 340 x 310 mm - Container quantity (20"/40"/40"HC) 1260 | 2620 | 3070




















Available as special accessories



18V 30min Power X-Change

Charger Item No.: 4512011

Bar Code: 4006825587029

Einhell Accessory



Guide rail Alu 2x1000mm Circular Saw Accessory Item No.: 4502118 Bar Code: 4006825632675

Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698

Einhell Accessory



18V 4,0 Ah Power-X-Change

Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



Power-X-Boostcharger 6 A

Charger Item No.: 4512064

Bar Code: 4006825629019

Einhell Accessory



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704

Einhell Accessory



18V 5,2 Ah P-X-C Plus

Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



cutting length (chipboard 19 mm, in m)

Usage	sawing	
Unit of measure	m	
1.5 Ah PXC	25	
2.0 Ah PXC	33	
2.5 Ah PXC	38	
2.6 Ah PXC+	42	
3.0 Ah PXC	49	
4.0 Ah PXC	64	
5.2 Ah PXC+	82	
4-6 Ah PXC+ (4.0 Ah)	64	
4-6 Ah PXC+ (6.0 Ah)	98	