



Cordless Lawn Mower

GE-CM 18/30 Li-Solo

ltem No.: 3413157

Ident No.: 11017

Bar Code: 4006825631869

The Einhell GE-CM 18/30 Li - Solo cordless lawn mower is a powerful helper for maintaining lawns. Recommended for lawn areas up to 150m². For a long service life the mower has an Einhell brushless motor and a high-quality impact-resistant plastic housing. Practical features include the folding long handle for compact storage, the integrated carry handle for easy transportation and the 3-level axial cutting height adjustment facility. Large wheels exert less stress on the lawn. The system battery and charger are available separately.

Features & Benefits

- Member of the Power X-Change family, 1x18V battery necessary
- Einhell Brushless Motor
- Axial cutting height adjustment, 3 levels
- Long handle folding
- Integrated carry-handle for easy transport
- Grass protecting, large wheels
- High quality, blow tough plastic housing
- Recommended for lawn areas up to 150 m²
- Supplied without battery and charger (available separately)

Technical Data

- Idle speed
- Cutting width
- Cutting height adjustment
- Capacity of catching device
- Wheel diameter front
- Wheel diameter rear

Logistic Data

- Gross weight (kg)
- Product weight (kg)
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

10.43 8.87 605 x 395 x 375 mm 1 Pieces 10.64 kg 605 x 395 x 375 mm 312 | 642 | 749

3300 min^-1

3 | 30-70 mm | axial wheel

30 cm

251

140 mm

140 mm









Available as special accessories



Spare Blade Lawn Mower Accessory Item No.: 3404553 Bar Code: 4006825633092 Einhell Accessory

18V 2,0Ah Power X-Change Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory

Einhell Accessory





18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory









Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory

18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 **Einhell Accessory**

18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 **Einhell Accessory**

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Battery-Running-Times

	₩	
One Battery for All	lawn mowing ¹	
	(m²)	
1.5 Ah	30	
2.0 Ah	70	
2.5 Ah	100	
3.0 Ah	150	
4.0 Ah	210	
5.2 Ah	270	
6.0 Ah	300	

For best performance select a battery with at least 2.5 Ah

Test setup:

1) -