







**GE-CM 18/30 Li (1x3,0Ah)** 

Item No.: 3413155

Ident No.: 11017

Bar Code: 4006825629163

The Einhell GE-CM 18/30 Li cordless lawn mower is a powerful helper for maintaining lawns. Recommended for lawn areas up to 150m². The rechargeable battery from the Power X-Change family can be used in all the devices from the system series. Three LEDs show the charge status at a glance. For a long service life the mower has an Einhell brushless motor and a high-quality impact-resistant plastic housing. Practical features include the folding long handle for compact storage, the integrated carry handle for easy transportation and the 3-level axial cutting height adjustment facility. Large wheels exert less stress on the lawn. The product is supplied with a rechargeable battery and a system charger.

OWER X-CHANGE

#### Features & Benefits

- Battery system Power X-Change
- Battery capacity indicator with 3 LEDs
- Accu can be used for all the tools in the Power X-Change family
- System charger included
- Einhell Brushless Motor
- Axial cutting height adjustment, 3 levels
- Long handle folding
- Integrated carry-handle for easy transport
- Grass protecting, large wheels
- High quality, blow tough plastic housing
- Recommended for lawn areas up to 150 m<sup>2</sup>

#### **Technical Data**

- Accumulator 18 V | 3 Ah | Li-Ion - Idle speed 3300 min^-1

- Cutting width 30 cm

- Cutting height adjustment 3 | 30-70 mm | axial wheel - Capacity of catching device 25 I - Wheel diameter front 14 cm

- Wheel diameter rear 14 cm

## **Logistic Data**

- Gross weight (kg) 11.55 - Product weight (kg) 9.32

605 x 395 x 375 mm - Dimensions single packaging

- Pieces per export carton 1 Pieces - Gross weight export carton 11.8 kg

- Dimensions export carton 605 x 395 x 375 mm - Container quantity (20"/40"/40"HC) 312 | 642 | 749





















# Available as special accessories



Spare Blade Lawn Mower Accessory Item No.: 3404553 Bar Code: 4006825633092 Einhell Accessory



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395



18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376



Einhell Accessory

18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698

**Einhell Accessory** 

Bar Code: 4006825610369



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory

Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory

## **Battery-Running-Times**

	300	
One Battery for All	lawn mowing <sup>1</sup>	
<u> </u>	(m²)	
1.5 Ah	30	
2.0 Ah	70	
2.5 Ah	100	
3.0 Ah	150	
4.0 Ah	210	
5.2 Ah	270	
6.0 Ah	300	

For best performance select a battery with at least 2.5 Ah

Test setup:

1) -