



# Einhell

## CLASSIC



Cordless Lawn Trimmer

**GC-CT 18/24 Li P-Solo**

**Item No.: 3411104**

Ident No.: 11018

Bar Code: 4006825635690

The Einhell GC-CT 18/24 Li P-Solo cordless grass trimmer is the ideal helper for bringing the garden and strips of grass into shape. The cordless grass trimmer is a member of the Power X-Change family. The powerful system batteries are used in all tools across the series. 1 x 18 V battery is required for operation. For comfortable working without fatigue there is an additional handle for two-handed operation. The housing and the secondary handle are made of impact-proof, high-grade plastic. The cutting width is 24 cm with a speed of 8,500 rpm. The product is supplied complete with 20 plastic blades. The system battery and charger are available separately.

## Features & Benefits

- Member of the Power-X-Change family, 1x18V batteries necessary
- Fatigue-free and agile operation thanks to low weight
- User-friendly two-hand operation thanks to additional handle
- Housing and handle made of impact-resistant, high-grade plastic
- Incl. 20 plastic blades
- Supplied without battery and charger (available separately)

## Technical Data

- |                          |          |
|--------------------------|----------|
| - Revolutions of knife   | 8500 rpm |
| - Cutting width of knife | 24 cm    |
| - Number of accumulators | 0 Pieces |

## Logistic Data

- |                                      |                    |
|--------------------------------------|--------------------|
| - Product weight                     | 1.2 kg             |
| - Gross weight single packaging      | 2 kg               |
| - Dimensions single packaging        | 180 x 150 x 490 mm |
| - Pieces per export carton           | 8 Pieces           |
| - Gross weight export carton         | 17 kg              |
| - Dimensions export carton           | 635 x 505 x 390 mm |
| - Container quantity (20"/40"/40"HC) | 1600   3280   3936 |



ADDITIONAL HANDLE



EASY HANDLING




INCL. 20 Pcs BLADES



1 x 18V BATTERY POWERED (NOT INCLUDED)



**18 V**



**24 cm**



**LOW WEIGHT  
EASY HANDLING**

## Available as special accessories



Ersatzmesser-Set PXC Trimmer  
Lawn Trimmer Accessory  
Item No.: 3405730  
Bar Code: 4006825560404  
Einhell Grey



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory




18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 trimming <sup>1</sup> (min.)
1.5 Ah	40
2.0 Ah	55
2.5 Ah	65
3.0 Ah	80
4.0 Ah	125
5.2 Ah	160
6.0 Ah	180

Test setup:

1) -