



Einhell

EXPERT PLUS



Cordless Lawn Trimmer

GE-CT 18 Li-Solo

Item No.: 3411172

Ident No.: 11047

Bar Code: 4006825588255

The GE-CT 18 Li Solo cordless grass trimmer is a powerful tool which helps you keep your lawn looking immaculate in those places which cannot be reached by a lawn mower. Thanks to its low weight and handy size the tool provides good service for the trimming of large grounds and allotments where there is no connection to the electric power grid.

Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Infinitely adjustable second handle
- Telescopic long handle, infinitely adjustable
- Motor head rotatable +/- 90° for vertical surfaces + lawn edges
- Motor head can be tilted to 5 settings
- Flower guard
- Compartment for 20 blades integrated in second handle
- Incl. 20 plastic blades
- Soft grip
- Supplied without battery and charger (available separately)

Technical Data

- Revolutions of knife 8500 rpm
- Cutting width of knife 24 cm

Logistic Data

- Product weight 1.75 kg
- Gross weight single packaging 2.71 kg
- Dimensions single packaging 960 x 190 x 110 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 10.86 kg
- Dimensions export carton 980 x 395 x 240 mm
- Container quantity (20"/40"/40"HC) 1044 | 2160 | 2400



TILT- AND TURNABLE



TELESCOPIC




FLOWERGUARD



1x18V BATTERY POWERED (NOT INCLUDED)



18 V



24 cm



5 x TILTABLE

Available as special accessories



Ersatzmesser-Set PXC Trimmer
Lawn Trimmer Accessory
Item No.: 3405730
Bar Code: 4006825560404
Einhell Grey



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 trimming ¹⁾ (min.)
1.5 Ah	40
2.0 Ah	55
2.5 Ah	65
3.0 Ah	80
4.0 Ah	125
5.2 Ah	160
6.0 Ah	180

Test setup:

1) -