







GE-CT 18 Li Kit (1x2,0Ah)

Item No.: 3411197

Ident No.: 11027

Bar Code: 4006825615418

The GE-CT 18 Li Kit cordless grass trimmer is a powerful tool which helps you keep your lawn looking immaculate in those places which cannot be reached by a lawn mover. With the new Power X-Change battery system from Einhell, the grass trimmer has an 18 V battery pack with 2.0 Ah for long work sessions where there is no connection to the power grid. Thanks to the battery capacity indicator with three LEDs you can check the current

WER X-CHANGE

Features & Benefits

- Battery system - Power X-Change

charge level at a glance.

- Battery charge level indicator with 3 LEDs
- Batteries can be used for other Power X-Change products
- System high-speed chargers included
- Infinitely adjustable second handle
- Telescopic long handle, infinitely adjustable
- Motor head rotateable +/- 90° for vertical surfaces + lawn edges
- Motor head can be tilted to 5 settings
- Flower guard
- Compartment for 20 blades integrated in second handle
- Incl. 20 plastic blades
- Soft grip

Technical Data

18 V | 2000 mAh | Li-Ion - Accumulator - Max. running time 55 min - Charging time 40min - Revolutions of knife 8500 rpm - Cutting width of knife 24 cm - Number of accumulators 1 Pieces

Logistic Data

- Product weight 2.15 kg - Gross weight single packaging 3.77 kg

200 x 120 x 982 mm - Dimensions single packaging

- Pieces per export carton 4 Pieces - Gross weight export carton 16.5 kg

1005 x 420 x 270 mm - Dimensions export carton - Container quantity (20"/40"/40"HC) 900 | 1984 | 2232



















Available as special accessories



Ersatzmesser-Set PXC Trimmer Lawn Trimmer Accessory Item No.: 3405730 Bar Code: 4006825560404

Einhell Grey



18V 2,0Ah Power X-Change Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 **Einhell Accessory**



18V 5,2Ah Power X-Change Plus

Battery Item No.: 4511437

Bar Code: 4006825616606 Einhell Accessory



18V 3,0 Ah Power-X-Change

Battery

Item No.: 4511341

Bar Code: 4006825590593 Einhell Accessory



Power X-Boostcharger 6A

Charger Item No.: 4512064

Bar Code: 4006825629019

Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396

Bar Code: 4006825610376

Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704

Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069

Bar Code: 4006825629729 Einhell Accessory

Battery-Running-Times

One Battery for All	trimming ¹
	(min.)
1.5 Ah	40
2.0 Ah	55
2.5 Ah	65
3.0 Ah	80
4.0 Ah	125
5.2 Ah	160
6.0 Ah	180

Test setup:

1) -