



# Einhell

## EXPERT PLUS



Cordless Grout Cleaner

**GE-CC 18 Li-Solo**

**Item No.: 3424050**

Ident No.: 11016

Bar Code: 4006825615982

The Einhell GE-CC 18 Li Solo cordless paving scraper is a practical Power X-Change set for improving the appearance of the garden and extending the life of hard-surfaced areas. The brushes are replaceable, with a nylon brush and a steel brush supplied with this product. The telescopic long handle is infinitely adjustable to enable work to be performed standing upright. For even easier handling and accurate cleaning results there is an inf. adj. second handle. The Softgrip ensures that the user feels comfortable while working. All system batteries from the Power X-Change series can be used in the cordless paving scraper. Supplied without battery and without charger.

## Features & Benefits


- Member of the Power X-Change family, 1x18V batteries necessary
- Dead man's safety switch
- Infinitely adjustable second handle
- Telescopic long handle, infinitely adjustable
- Replaceable brushes (1x nylon and 1x steel included)
- Guide wheel
- Soft grip
- Supplied without battery and charger (available separately)

## Technical Data

- Diameter of brush 100 mm
- Idle speed 1200 min<sup>-1</sup>

## Logistic Data

- Product weight (kg) 2.04
- Gross weight (kg) 2.57
- Dimensions single packaging 875 x 200 x 120 mm
- Pieces per export carton 4 Pieces
- Gross weight of export carton 11.3 kg
- Dimensions export carton 1000 x 420 x 280 mm
- Container quantity (20"/40"/40"HC) 898 | 1728 | 2160



## Available as special accessories

Ersatzbuerste Stahl GC-EG 1410  
Grout Cleaner Accessory  
Item No.: 3424100  
Bar Code: 4006825569919  
Einhell Grey



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



Ersatzbuerste Nylon GC-EG 1410  
Grout Cleaner Accessory  
Item No.: 3424110  
Bar Code: 4006825569926  
Einhell Grey

18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory





Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V 3,0 Ah Power-X-Change  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 cleaning <sup>1</sup> (min.)	 cleaning <sup>2</sup> (min.)
	1.5 Ah	30
2.0 Ah	45	45
2.5 Ah	50	50
3.0 Ah	60	60
4.0 Ah	90	90
5.2 Ah	120	120
6.0 Ah	135	135

### Test setup:

1) nylon

2) metal