



Einhell

EXPERT PLUS



Cordless Grout Cleaner

GE-CC 18 Li Kit (1x2,0Ah)

Item No.: 3424051

Ident No.: 11016

Bar Code: 4006825618396

The Einhell GE-CC 18 Li Kit cordless paving scraper is a practical Power X-Change set for improving the appearance of the garden and extending the life of hard-surfaced areas. The brushes are replaceable, with a nylon brush and a steel brush supplied with this product. The telescopic long handle is infinitely adjustable to enable work to be performed standing upright. For even easier handling and accurate cleaning results there is an inf. adj. second handle. The Softgrip ensures that the user feels comfortable while working. The Power X-Change system battery with LED charge indicator included in the scope of delivery can be used in all Power X-Change models and the supplied high-speed charger system can be used for all system batteries.

Features & Benefits




- Battery system - Power X-Change
- Battery charge level indicator with 3 LEDs
- Batteries can be used for other Power X-Change products
- System high-speed chargers included
- Dead man's safety switch
- Infinitely adjustable second handle
- Telescopic long handle, infinitely adjustable
- Replaceable brushes (1x nylon and 1x steel included)
- Guide wheel
- Soft grip

Technical Data

- Diameter of brush 100 mm
- Idle speed 1200 min⁻¹
- Accumulator 18 V | 2000 mAh | Li-Ion

Logistic Data

- Product weight (kg) 2.4
- Gross weight (kg) 3.7
- Dimensions single packaging 855 x 200 x 120 mm
- Pieces per export carton 4 Pieces
- Gross weight of export carton 15.4 kg
- Dimensions export carton 1000 x 420 x 280 mm
- Container quantity (20"/40"/40"HC) 898 | 1728 | 2160



Available as special accessories

Ersatzbuerste Stahl GC-EG 1410
Grout Cleaner Accessory
Item No.: 3424100
Bar Code: 4006825569919
Einhell Grey



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

Ersatzbuerste Nylon GC-EG 1410
Grout Cleaner Accessory
Item No.: 3424110
Bar Code: 4006825569926
Einhell Grey



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory





18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 cleaning ¹ (min.)	 cleaning ² (min.)
	1.5 Ah	30
2.0 Ah	45	45
2.5 Ah	50	50
3.0 Ah	60	60
4.0 Ah	90	90
5.2 Ah	120	120
6.0 Ah	135	135

Test setup:

1) nylon

2) metal