





**Cordless Planer** 

**TE-PL 18/82 Li - Solo** 

Item No.: 4345400

Ident No.: 11019

Bar Code: 4006825645934

The cordless planer Einhell TE-PL 18/82 Li - Solo is a high-performance hand-held planer for applications with a chip depth up to 2 mm. Large knife shafts and a solid aluminium soleplate deliver optimum, flat results. The soleplate has a V-shaped groove for easy chamfering. There is an automatic parking rest to protect both the planer and the workpiece. The ergonomic handle and soft grip ensure tireless and comfortable operation. The product is supplied with a parallel guide, a rebate depth stop and a TCT planing knife (reversible blade) for an excellent surface finish. As a member of the Power X-Change series, all the rechargeable batteries from the series can be used. 2.5 Ah Plus rechargeable batteries or higher are recommended.

WER CHANGE

## **Features & Benefits**

- Member of the Power X-Change family
- Powerful hand-held planer for jobs with a chip depth of up to 2mm
- Large knife shaft for optimum planing results
- Automatic park rest protecting the planing knife and workpiece
- Solid aluminium soleplates for flat results
- Soleplate with 1 V-shaped groove for easy chamfering of edges
- Ergonomic handle for working without fatigue
- Safe and user-friendly handling due to soft grip
- Incl. parallel guide for straight and precise planing results
- Incl. rebate depth stop for making recesses with ease
- Incl. 1x TCT planing knife for a high surface quality
- Recommendation for optimum results: 2.5 Ah Plus battery & higher

82 mm

2 mm

8 mm

- Supplied without battery and charger (available separately)









## **Logistic Data**

**Technical Data** 

- Planing width

- Planing depth

- Depth

- Product weight (kg) 2.44 3 3244 - Gross weight (kg)

- Dimensions single packaging 289 x 180 x 187 mm

- Pieces per export carton 4 Pieces - Gross weight of export carton 14 kg

- Dimensions export carton 375 x 305 x 395 mm - Container quantities (20"/40"/40"HC) 2400 | 4800 | 6040











## Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory

## **Battery-Running-Times**

One Battery for All	planing¹ (m)
1.5 Ah	16
2.0 Ah	25
2.5 Ah	28
3.0 Ah	37
4.0 Ah	48
5.2 Ah	58
6.0 Ah	78

For best performance select a battery with at least 2.5 Ah

Test setup:

1)