







Cordless Scarifier / Aerator

GC-SC 36/31 Li-Solo

Item No.: 3420660

Ident No.: 11029

Bar Code: 4006825636956

The Einhell Cordless Scarifier GC-SC 36/31 Li-Solo is a professional lawn care tool. It is recommended for lawns up to 300 m2. As a member of the Power X-Change family, the batteries fit all products in this range. Two 18 V batteries power the series-wound motor. The eight double blades are mounted on the ball bearing-mounted blade cylinder, which is made of sturdy stainless steel. The working depth can be adjusted to three levels and to a transport position. The handle is height-adjustable and foldable. The large wheels protect the lawn, and the housing is made of impact-resistant plastic. The GC-SC 36/31 Li can be optionally upgraded to a 3-in-1 combination tool (aerator shaft/collection basket). Supplied without batteries or a charger.

Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Powerful series motor
- Ball-bearing scarifier drum with 8 stainless steel double-knives.
- Scarifying depth adjustment, 3 levels + transport position
- Foldable and height adjustable guide rail.
- Wide wheels exert less stress on the lawn
- Impact-resistant plastic housing
- Recommended for lawn areas up to 300 m² (depending on batteries)
- Supplied without battery and charger (available separately)
- Optional extensible with aerator roller and catch bag

Technical Data

- Working width 31 cm - Number of knives 8 Pieces - Wheel diameter front 18 cm - Wheel diameter rear 10 cm - Capacity of catch bag 28 I

Logistic Data

- Tool weight 7.95 kg - Gross Weight 9.95 kg

- Dimensions single packaging 600 x 465 x 328 mm

- Pieces per export carton 1 Pieces - Gross weight of export carton 9.95 kg

- Dimensions export carton 600 x 460 x 330 mm - Container quantity (20"/40"/40"HC) 320 | 670 | 765





















Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064

Bar Code: 4006825629019 Einhell Accessory

Messerwalze GC-ES/SA 1231/1 Scarifier Accessory Item No.: 3405582 Bar Code: 4006825629682

Einhell Accessory



18V 2,0Ah Power X-Change

Battery

Item No.: 4511395 Bar Code: 4006825610369

Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698

Einhell Accessory



18V 5,2Ah Power X-Change Plus

Battery

Item No.: 4511437

Bar Code: 4006825616606 Einhell Accessory



Lüfterwalze GC-ES/SA 1231/1 Scarifier Accessory Item No.: 3405572 Bar Code: 4006825629675

Einhell Accessory



Fangsack GC-ES/SA 1231/1 Scarifier Accessory Item No.: 3405577 Bar Code: 4006825629699

Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376

Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



Power X-Twincharger 3A

Charger

Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Battery-Running-Times

	$lackbox{}$
One Battery for All	scarifying ¹
	(m²)
1.5 Ah	80
2.0 Ah	100
2.5 Ah	130
3.0 Ah	200
4.0 Ah	250
5.2 Ah	300
6.0 Ah	350

For best performance select a battery with at least 2.5 Ah

1) -