



Einhell

EXPERT PLUS



Power Tool Kit

TE-TK 18 Li Kit (CD+AG)

Item No.: 4257211

Ident No.: 21030

Bar Code: 4006825613711

The Einhell TE-TK 18 Li Kit (CD+AG) is a set which comprises two Power X-Change members: The TE-CD 18/2 Li drill & driver and the TE-AG 18/115 Li angle grinder, plus one 1.5 Ah and one 3.0 Ah battery and a 30 minute high-speed charger. The TE-CD 18/2 Li drill & driver with powerful motor and two-speed metal gearing has a Quick Stop function, torque slip coupling and a single-sleeve quick-change drill chuck. The TE-AG 18/115 Li cordless angle grinder with its softstart function ensures a smooth start, the restart safeguard makes it safer to use and the modified air guidance provides better cooling. The disk guard comes with a quick-adjust facility for adjustment to every situation.

Features & Benefits



- Power X-Change Tool Kit
- Cordless Drill TE-CD 18/2 Li - Solo
- Powerful motor and 2-speed metal gearing
- Single-sleeve chuck with quick-stop
- Torque slip coupling for sensitive operation
- Cordless Angle Grinder TE-AG 18/115 Li - Solo
- Softstart function and restart safeguard to make it safer to use
- Modified air guidance for better cooling and longer service life
- Disk guard with quick adjust facility
- Incl. 1.5 Ah & 3.0 Ah battery and high-speed charger



Technical Data

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 3.3 |
| - Gross weight (kg) | 5.78 |
| - Dimensions single packaging | 315 x 235 x 220 mm |
| - Product weight | 3.3 kg |
| - Pieces per export carton | 2 Pieces |
| - Gross weight single packaging | 5.78 kg |
| - Gross weight export carton | 12.2 kg |
| - Dimensions export carton | 505 x 340 x 245 mm |
| - Container quantity (20"/40"/40"HC) | 1374 2850 3342 |



Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack
Battery
Item No.: 4511518
Bar Code: 4006825651676
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



2x 3,0Ah & 30min PXC Kit
PXC-Starter-Kit
Item No.: 4512098
Bar Code: 4006825646986
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack BP 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory