



#### **Cordless Hedge Trimmer**

GE-CH 1846 Li-Solo

Item No.: 3410642

Ident No.: 11037

Bar Code: 4006825588293

The GE-CH 1846 Li cordless hedge trimmer is an efficient tool which thanks to its low weight and handy size provides good service for the trimming of hedges, shrubs and bushes on large grounds and allotments where there is no connection to the electric power grid. For a long service life the gearing is made of metal, for clean cutting results the blades are made of laser-cut and diamond-ground steel.

## **Features & Benefits**

- Small and easy to handle
- Low weight for user-friendly operation
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Blades made of laser-cut and diamond-ground steel
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)

## **Technical Data**

- Blade length	
- Cutting length	
- Spacing between teeth	
- Cuts per minute	

# Logistic Data

-	Product	weight
---	---------	--------


- Gross weight single packaging
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions Export Carton
- Container quantity (20"/40"/40"HC)

2 kg 2.84 kg 892 x 180 x 185 mm 4 Pieces 12.4 kg 915 x 375 x 265 mm 1152 | 2400 | 3000

520 mm 460 mm 15 mm 2200 min^-1











### Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory





18V 4,0Ah Power X-Change Battery Item No.: 4511396

Bar Code: 4006825610376 **Einhell Accessory** 

18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 **Einhell Accessory** 

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory







18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698

18V 2,0Ah Power X-Change

Bar Code: 4006825610369

Battery Item No.: 4511395

Einhell Accessory

**Einhell Accessory** 

18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 **Einhell Accessory** 

18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory

## **Battery-Running-Times**

One Battery for All	running time <sup>1</sup>
	(min.)
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240

Test setup:

1) -