



#### **Cordless Hedge Trimmer**

#### GE-CH 1846 Li Kit (1x2,0Ah)

Item No.: 3410683

Ident No.: 11027

Bar Code: 4006825615432

The GE-CH 1846 Li Kit cordless hedge trimmer is an efficient tool which thanks to its low weight and handy size provides good service for the trimming of hedges, shrubs and bushes on large grounds and allotments where there is no connection to the electric power grid. With the new Power X-Change battery system from Einhell, the hedge trimmer has an 18 V battery pack with 2.0 Ah for long work sessions.

### **Features & Benefits**

- Battery system Power X-Change
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- System high-speed charger included
- Small and easy to handle
- Low weight for user-friendly operation
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover on cutters
- Bumper guard with holder for wall mount
- Blades made of laser-cut and diamond-ground steel
- Sturdy cutter guard for storage and transportation

# **Technical Data**

- Max. running time
- Charging time
- Cutting length
- Blade length
- Spacing between teeth
- Cuts per minute
- Accumulator
- Number of accumulators

# **Logistic Data**

- Product weight2.- Gross weight single packaging3.- Dimensions single packaging90- Pieces per export carton4- Gross weight export carton14- Dimensions Export Carton94- Container quantity (20"/40"/40"HC)11


40min 460 mm 520 mm 15 mm 2200 min^-1 18 V | 2000 mAh | Li-Ion 1 Pieces

80 min

2.3 kg 3.98 kg 907 x 175 x 180 mm 4 Pieces 14 kg 940 x 380 x 270 mm 1152 | 2368 | 2664









### Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory







18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 **Einhell Accessory** 

18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 **Einhell Accessory** 

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory







18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory

18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 **Einhell Accessory** 

18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 **Einhell Accessory** 

18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory

# **Battery-Running-Times**

One Battery for All running time <sup>1</sup> (min.)	
(1111.)	
<b>1.5 Ah</b> 60	
<b>2.0 Ah</b> 80	
<b>2.5 Ah</b> 100	
<b>3.0 Ah</b> 120	
<b>4.0 Ah</b> 160	
<b>5.2 Ah</b> 210	
<b>6.0 Ah</b> 240	

Test setup:

1) -