







CI Pole-Mounted Powered Pruner

GE-LC 18 Li T-Solo

Item No.: 3410810

Ident No.: 11014

Bar Code: 4006825604337

The cordless pole pruner GE-LC 18 Li T is a powerful device which makes it possible to cut branches aloft effortlessly and independently from the power supply from the ground. Thereby, the metal gearbox provides a long duration, and the OREGON-quality blade and the OREGON-chain care for clean cutting results. By means of its various setting options, the pole pruner can be adjusted to each working situation. The automatic chain lubrication and the chain exchange without tools allow a simple handling. Battery and charger are not included in delivery.

Features & Benefits

- 90° pivotable attachment for effortless horizontal cuts
- Motor head tiltable by 7 settings
- Main handle tiltable by 4 settings
- Continuously adjustable telescopic aluminium handle (880-1820 mm)
- Additional adjustable handle with quick fastener
- OREGON quality blade and chain
- Toolless chain tensioning and chain change
- Metal gearing for a long life
- Claw stop
- Chain catch bolt
- Carrying belt
- Oil tank for automatic chain lubrication
- Supplied without battery and charger (available separately)

Technical Data

- Sword length 200 mm 170 mm - Cutting length 3.76 m/s - Cutting speed - Length of telescope bar 183 - 277 cm

Logistic Data

- Product weight 3.96 kg - Gross weight single packaging 4.95 kg

- Dimensions single packaging 205 x 122 x 1215 mm

- Pieces per export carton 3 Pieces - Gross weight export carton 15.9 kg

- Dimensions export carton 1230 x 370 x 245 mm - Container quantity (20"/40"/40"HC) 750 | 1551 | 1701





















Available as special accessories



Ersatzschwert 20cm 1,3 Chain Saw Accessory Item No.: 4500168 Bar Code: 4006825606348

Einhell Grey



Heckenschere f. GE-LC 18 Li T Multifunctional Tool-GT Acces. Item No.: 3410818 Bar Code: 4006825624649

Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396

Bar Code: 4006825610376 **Einhell Accessory**



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704

Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 3,0Ah Power X-Change Plus

Battery Item No.: 4511501 Bar Code: 4006825644197

Einhell Accessory



2x 3,0Ah & 30min PXC Kit PXC-Starter-Kit Item No.: 4512098 Bar Code: 4006825646986

Einhell Accessory



2x18V 4,0Ah PXC-Twinpack BP 1

Battery

Item No.: 4511489 Bar Code: 4006825638578

Einhell Accessory



Spare Chain 20cm 1,3 33T 3/8 Chain Saw Accessory Item No.: 4500188 Bar Code: 4006825606355 Einhell Grey



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 **Einhell Accessory**



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory

Battery-Running-Times

One Battery for All	cutting ¹
	(pieces)
1.5 Ah	30
2.0 Ah	40
2.5 Ah	48
3.0 Ah	60
4.0 Ah	75
5.2 Ah	100
6.0 Ah	120

For best performance select a battery with at least 2.5 Ah

Test setup:

1) scantling 70x70 mm