





Cordless Drill

TE-CD 18 Li mit 2. Akku Kit

Item No.: 4513687

Ident No.: 11024

Bar Code: 4006825602708

The TE-CD 18 Li cordless drill/screwdriver with 2nd battery is a reliable and versatile DIY tool which makes drilling and screwdriving jobs around the home, workshop and garage much easier. The rugged 2-speed metal gearing and powerful motor generate high torque, delivering plenty of power for screwdriving amd high-speed drilling. The tool is supplied with two 1.5 Ah rechargeable batteries and fast charger. Therefore you are enabled to work without interruptions.

WER X-CHANGE

Features & Benefits

- Member of the Power X-Change family
- 2-speed gearing for powerful screwdriving and fast drilling
- Powerful motor and metal gearing deliver high torque
- Single-sleeve chuck and quick stop for fast drill bit change
- Automatic spindle lock for easy tool change
- Speed control for fine adjustment on delicate jobs
- Overload slip coupling prevents over-turning of screws
- Ergonomic soft grip for comfortable operation
- Direction indicator on the tool
- Incl. LED lamp to illuminate the work area
- Complete with practical belt clip
- Incl. two 1.5 Ah rechargeable batteries and fast charger
- Incl. practical case

Technical Data

- Accumulator 18 V | 1500 mAh | Li-Ion

1/2h - Charging time - Number of gears 2

- Idle speed (gear 1) 0-320 min^-1 - Idle speed (gear 2) 0-1350 min^-1

- Max. torque hard 48 Nm - Number of torque steps 24 settings

- Drill chuck 10 mm | single sleeve

- Number of accumulators 2 Pieces

Logistic Data

- Product weight 1.5 kg - Gross weight single packaging 4.2 kg

- Dimensions single packaging 420 x 105 x 335 mm

- Pieces per export carton 4 Pieces - Gross weight export carton 17.6 kg

- Dimensions export carton 450 x 430 x 365 mm - Container quantity (20"/40"/40"HC) 1560 | 3120 | 3640

















Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



18V 4,0Ah PXC Starter Kit TP PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory

Battery-Running-Times

One Battery for All	screwing ¹
	(pieces)
1.5 Ah	180
2.0 Ah	240
2.5 Ah	300
3.0 Ah	360
4.0 Ah	480
5.2 Ah	625
6.0 Ah	720

Test setup:

1) screws - 6x60 mm