







#### **TE-OS 18/150 Li Solo**

Item No.: 4460708

Ident No.: 21020

Bar Code: 4006825651218

WER X-CHANGE

The cordless multiple sander TE-OS 18/150 Li - Solo is a compact and handy sander from Power X-Change family of devices which combines the best ergonomics with maximum functionality for lending surfaces a good finish. The ergonomic grip area with soft grip is good to hold. Experts appreciate the tool as an indispensable helper which really demonstrates its strengths particularly on small and hard-to-reach surfaces. The tool is supplied without battery and charger but it can be powered by Power X-Change rechargeable batteries.

#### Features & Benefits

- Member of the Power X-Change family
- Grip area with softgrip modeled on the palm of a hand
- Small, compact and easy to handle
- Flexible in use for sanding corners and small surfaces
- "Extreme Fix" fastening for quick change of abrasive paper
- High removal rate with "Extreme Fix" due to reduced slippage
- Solid, rugged aluminium fan impeller for smooth running
- Active dust extraction keeps the work area clean
- Filter box for sanding dust (only 1.5/2.0/2.5/2.6/3.0+Ah batt.)
- Incl. vacuum cleaner adapter (with every battery usable)
- Incl. six sheets of abrasive paper (3\*P120/3\*P240)
- Supplied without battery and charger (available separately)

### **Technical Data**

24000 min^-1 - Oscillating speed - Oscillating circuit 1.6 mm

- Grinding (sanding) surface (delta) 150 x 150 x 100 mm 150 x 150 x 100 mm - Sanding paper size

## **Logistic Data**

- Product weight (kg) 0.79 - Gross weight (kg) 1.14

- Dimensions single packaging 257 x 157 x 110 mm

- Pieces per export carton 8 Pieces - Gross weight of export carton 10.7 kg

- Dimensions Export Carton 465 x 225 x 310 mm - Container quantity (20"/40"/40"HC) 6048 | 12600 | 0



















## Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack BP 1 Battery Item No.: 4511489 Bar Code: 4006825638578



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Einhell Accessory

# **Battery-Running-Times**

One Battery for All	sanding <sup>1</sup>	
	(min.)	
1.5 Ah	23	
2.0 Ah	27	
2.5 Ah	34	
3.0 Ah	40	
4.0 Ah	55	
5.2 Ah	70	
6.0 Ah	80	

Test setup:

1) wood - pine wood