



# Einhell

## EXPERT



Cordless Mini Circular Saw

**TE-CS 18/89 Li - Solo**

**Item No.: 4331100**

Ident No.: 11019

Bar Code: 4006825646184

The Einhell TE-CS 18/89 Li - Solo cordless mini hand-held circular saw is compact, light and user-friendly – comfortable to handle and therefore work with. As a member of the Power X-Change family, the mini hand-held circular saw can be used in combination with every PXC rechargeable battery. The battery and charger from the PXC series are not included in the scope of this delivery and are available separately. The cutting depth can be adjusted without tools. Changing the saw blade is also simplicity itself thanks to the spindle locking system. The carbide saw blade and the parallel stop ensure clean, precise cuts and the max. cutting depth is 28 mm. The high-quality saw table made of aluminium provides optimum stability.

## Features & Benefits



- A member of the Power X-Change family
- Small, light and handy – for comfortable operation
- Easy, tool-free adjustment of the cutting depth
- High-quality saw table made of aluminium for optimum stability
- Easy changing of the saw blade thanks to the spindle lock
- High-grade carbide blade for clean cuts
- Max. cutting depth of 28 mm thanks to the Ø89 mm saw blade
- Dust extraction adapter to keep the workplace clean
- Parallel stop for precise cuts

## Technical Data

- Voltage	18 V
- rotation speed	2500 min <sup>-1</sup>
- saw blade diameter	89 mm
- Cutting depth wood	28 mm

## Logistic Data

- Product weight (kg)	1.77
- Gross weight (kg)	2.6
- Dimensions single packaging	431 x 137 x 152 mm
- Pieces per export carton	4 Pieces
- Gross weight of export carton	11 kg
- Dimensions export carton	445 x 285 x 325 mm
- Container quantities (20"/40"/40"HC)	2768   5680   6520



## Available as special accessories



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory




Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory

18V 4,0Ah PXC Starter Kit 2  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 sawing <sup>1</sup> (m)
1.5 Ah	26
2.0 Ah	36
2.5 Ah	50
3.0 Ah	57
4.0 Ah	72
5.2 Ah	104
6.0 Ah	120

Test setup:

1) -