





Cordless Drill

TE-CD 18/40 Li BL - Solo

Item No.: 4513997

Ident No.: 21010

Bar Code: 4006825658422

OWER X-CHANGE

The Einhell TE-CD 18/40 Li BL - Solo drill/screwdriver is powered by a brushless motor, which offers more power and runs longer. The small, light cordless drill/screwdriver with 2-speed gearing is easy to work with thanks to its ergonomic design, low weight and soft grip. Electronic speed control ensures that the tool can be adjusted to each particular material and application. The drill/screwdriver features a high-quality, single-sleeve quickchange chuck and LED lighting. The PXC rechargeable batteries are permanently ready-for-use thanks to the lithium-ion technology with zero selfdischarge. The product is supplied without a battery or charger from the Power X-Change series which are available separately.

Features & Benefits

- A member of the Power X-Change family
- Brushless motor more power and prolonged operation
- High-grade and single sleeve chuck
- 2-speed gearing for powerful drilling and screwing
- Speed electronics for material and application suitable working
- Always Ready-for-use due to Li-ion technology without discharging
- LED lighting for optimum operation in dark areas
- Extremely easy to work with due to ergonomic design and soft grip
- Small and light weight cordless drill for working without fatigue
- Supplied without battery and charger (available separately)

Technical Data

- Number of gears

- Idle speed (gear 1) 0-350 min^-1 - Idle speed (gear 2) 0-1450 min^-1 - Max. torque hard 40 Nm - Number of torque steps 21 settings

- Drill chuck 10 mm | single sleeve

- Number of accumulators 0 Pieces

Logistic Data

- Product weight 0.79 - Gross weight single packaging 0.95

- Dimensions single packaging 210 x 74 x 170 mm

- Pieces per export carton 8 Pieces - Gross weight export carton 9.3 kg

365 x 310 x 225 mm - Dimensions export carton

- Container quantity (20"/40"/40"HC) 8768 | 17592



















Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019



Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory