



CLASSIC

Cl. Telescopic Hedge Trimmer

GC-HH 18/45 Li T-Solo

Item No.: 3410585

Bar Code: 4006825652130

The Einhell cordless pole hedge trimmer belongs to the PXC system series from Einhell. The blades on the pole hedge trimmer are made of laser-cut and diamond-ground steel, flexibility is owed to a motor head with 7 tilt settings and a swiveling main handle. There is an additional rubberized holding area that provides a firm and secure grip, as well as a harness that also promotes ergonomic handling. The robust metal gearing is designed for a long service life. This pole hedge trimmer comes with an extension pole so that it can also be used on higher hedges. A sturdy cutter guard is supplied for safe storage and easy transport. It comes without a battery and without a charger; these items are available separately, e.g. as a starter set.

Features & Benefits

- Blade made of laser-cut and diamond-ground steel
- Motor head can be tilted to 7 settings
- Swiveling main handle
- Additional rubberized holding area for ergonomic handling
- Metal gearing for long life
- Extension pole for higher hedges
- Sturdy cutter guard for storage and transportation
- Carrying belt
- Supplied without battery or charger (available separately)

Technical Data

- Blade length	450 mm
- Max. cutting length	410 mm
- Spacing between teeth	18 mm
- Cuts per minute	1400 min^-1


Logistic Data

- Product weight (kg)
- Gross weight (kg)
- Dimensions single packaging
- Pieces per export carton
- Gross weight of export carton
- Dimensioins export carton
- Container quantity (20"/40"/40"HC)

3.17 5.09 228 x 140 x 1170 mm 3 Pieces 17 kg 1185 x 440 x 245 mm 594 | 1344 | 1500







Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory

18V 2,5Ah PXC Starter Kit

Bar Code: 4006825646962

PXC-Starter-Kit

Item No.: 4512097

Einhell Accessory





18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory

18V 4,0Ah PXC Starter Kit 2 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory





ltem Ńo.: 4511395 Bar Code: 4006825610369 Einhell Accessory

Battery





18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory

2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083

Bar Code: 4006825638509

Bar Code: 4006825644197

18V 2,0Ah Power X-Change

18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501

Einhell Accessory

Einhell Accessory

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Battery-Running-Times

One Battery for All	running time ¹
	(min.)
1.5 Ah	20
2.0 Ah	28
2.5 Ah	33
3.0 Ah	40
4.0 Ah	56
5.2 Ah	66
6.0 Ah	80

Test setup:

1) -