







**GE-CM 18/30 Li (1x3,0Ah)** 

Item No.: 3413155

Ident No.: 21020

Bar Code: 4006825629163

The Einhell GE-CM 18/30 Li cordless lawn mower is a powerful helper for maintaining lawns. Recommended for lawn areas up to 150m². The rechargeable battery from the Power X-Change family can be used in all the devices from the system series. Three LEDs show the charge status at a glance. For a long service life the mower has an Einhell brushless motor and a high-quality impact-resistant plastic housing. Practical features include the folding long handle for compact storage, the integrated carry handle for easy transportation and the 3-level axial cutting height adjustment facility. Large wheels exert less stress on the lawn. The product is supplied with a rechargeable battery and a system charger.

OWER X-CHANGE

## Features & Benefits

- Incl. 1x Power X-Change system battery (3,0Ah)
- Battery capacity indicator with 3 LEDs
- Accu can be used for all the tools in the Power X-Change family
- System charger included
- Einhell Brushless Motor
- Axial cutting height adjustment, 3 levels
- Long handle folding
- Integrated carry-handle for easy transport
- Grass protecting, large wheels
- High quality, blow tough plastic housing
- Recommended for lawn areas up to 150 m<sup>2</sup>

## **Technical Data**

- Accumulator 18 V | 3000 mAh | Li-Ion - Charging time

- Idle speed 3300 min^-1 30 cm - Cutting width

- Cutting height adjustment 3 | 30-70 mm | axial wheel

25 L - Capacity of catching device - Wheel diameter front 140 mm - Wheel diameter rear 140 mm

## **Logistic Data**

- Gross weight (kg) 11.55 - Product weight (kg) 9.32

- Dimensions single packaging 605 x 395 x 375 mm

- Pieces per export carton 1 Pieces - Gross weight export carton 11.8 kg

- Dimensions export carton 605 x 395 x 375 mm - Container quantity (20"/40"/40"HC) 312 | 642 | 749





















## Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



Spare Blade Lawn Mower Accessory Item No.: 3404553 Bar Code: 4006825633092 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory



18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory