



Einhell

EXPERT



Cordless Hedge Trimmer

ARCURRA 18/55

Item No.: 3410920

Ident No.: 21031

Bar Code: 4006825635935

The Einhell ARCURRA 18/55 Cordless Hedge Trimmer is a powerful member of the Power X-Change family from Einhell and features laser-cut and diamond-ground steel blades. The ergonomic, narrow handle of the ARCURRA 18/55 is equipped with a micro-switch. The metal gearing ensures that this unit is built to last. The aluminum cover over the cutters protects the blades, and the sturdy cutter guard offers protection during storage and transport. Also included in the delivery is an impact protection guard with a holder for wall mounting and a practical collector for clippings. The unit is supplied without a battery and charger, which are available separately. An 18 V Power X-Change battery is required for operation of the Einhell ARCURRA 18/55.

Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Blades made of laser-cut and diamond-ground steel
- Ergonomic, small front handle with micro switches
- Metal gearing for a long life
- Cutting collector
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)




Technical Data



- Cutting length	550 mm
- Blade length	620 mm
- Spacing between teeth	18 mm
- Cuts per minute	2400 min ⁻¹

Logistic Data

- Product weight	2.85 kg
- Gross weight single packaging	4.29 kg
- Dimensions single packaging	1030 x 200 x 145 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	18.14 kg
- Dimensions Export Carton	1050 x 420 x 225 mm
- Container quantity (20"/40"/40"HC)	1044 2160 2400



ARCURRA



Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory

18V 4,0Ah PXC Starter Kit 2
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 2
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory