



EXPERT

Cordless Scarifier / Aerator

GC-SC 18/28 Li-Solo

Item No.: 3420604

Bar Code: 4006825655223

The Einhell GC-SC 18/28 Li Solo cordless scarifier provides cordless freedom in home grounds and gardens of up to 200 m² (recommended). Batteries from the PXC series are interchangeable. A brushless electric motor drives the cordless scarifier, which has a housing made of impact-resistant plastic. As an option it is available with an aerator roller and a catch basket as a 3-in-1 combination tool. The ball-bearing cutting unit has 12 rotating blades. For the user's comfort there are 3 working depth settings, a transport position, and a long handle that can be folded down and adjusted in height. Large wheels exert less stress on the lawn. One 18 V battery is needed for operation. Delivery does not included a battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Powerful brushless motor
- Ball-bearing scarifier drum with 12 rotating knives.
- Scarifying depth adjustment, 3 levels + transport position
- Foldable and height adjustable guide rail.
- Wide wheels exert less stress on the lawn
- Impact-resistant plastic housing
- Recommended for lawn areas up to 200 m² (depending on batteries)
- Supplied without battery and charger (available separately)
- Optional extensible with aerator roller and catch bag

Technical Data

- Working width
- Number of knives
- Wheel diameter front
- Wheel diameter rear
- 280 mm 12 Pieces 150 mm 100 mm

Logistic Data

- Tool weight
- Gross Weight
- Dimensions single packaging
- Pieces per export carton
- Gross weight of export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

6.65 kg 8.2 kg 505 x 480 x 242 mm 1 Pieces 8.2 kg 518 x 490 x 245 mm 396 | 828 | 920







Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 **Einhell Accessory**

18V 2.5Ah PXC Starter Kit

Bar Code: 4006825646962

PXC-Starter-Kit

Item No.: 4512097

Einhell Accessory





2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory

Power X-Twincharger 3A



Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Areator roller GC-SC 18/28 Li Scarifier Accessory Item No.: 3405941 Bar Code: 4006825658804 **Einhell Accessory** Scarifier rolle GC-SC 18/28 Li Scarifier Accessory

Item No.: 3405942 Bar Code: 4006825658811 **Einhell Accessory**

18V 4,0Ah PXC Starter Kit 2 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory

















Catch Bag GC-SC 18/28 Li Scarifier Accessory Item No.: 3405940 Bar Code: 4006825658798 **Einhell Accessory**

2x 18V 2,5Ah PXC-Twinpack CB

Battery Item No.: 4511524 Bar Code: 4006825656206

2x18V 4,0Ah PXC-Twinpack CB 2 Battery Item No.: 4511489 Bar Code: 4006825638578 **Einhell Accessory**

Battery-Running-Times

0.01

One Battery for All	scarifying ¹	
	(m²)	
1.5 Ah	60	
2.0 Ah	80	
2.5 Ah	100	
3.0 Ah	120	
4.0 Ah	160	
5.2 Ah	210	
6.0 Ah	240	

Test setup:

1) -




Bar Code: 4006825638509 Einhell Accessory 18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501

2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083

Bar Code: 4006825644197 **Einhell Accessory**

18V 4,0Ah Power X-Change

18V 2,5Ah Power X-Change





Bar Code: 4006825650518 Einhell Accessory 18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory

Einhell Accessory

Battery Item No.: 4511516