







TE-CS 18/190 Li BL - Solo

Item No.: 4331210

Ident No.: 11018

Bar Code: 4006825641547

The Einhell Cordless Handheld Circular Saw TE-CS 18/190 Li BL-Solo is part of the Power X-Change series and is compatible with all Einhell guide

rails. The brushless motor delivers more power and longer running times. The saw is easy to operate - with tool-free adjustment (cutting depth, tilt angle) and easy saw blade changes thanks to the spindle lock. The splitter adapts to the cutting depth, while the parallel stop and the carbide saw blade enable precise cuts. The large handle helps prevent fatigue when working, and the LED lighting ensures optimum illumination of the working area. The high-quality baseplate is made of aluminum and is equipped with a dust extraction adapter. This product comes without a battery or charger.

OWER X-CHANGE

Features & Benefits

- A member of the Power X-Change family
- Brushless motor more power and prolonged operation
- Easy adjustment without tools (cutting depth, tilt angle)
- Large handle for tireless working
- High-quality LED for optimum illumination of the cutting area
- High-quality baseplate made of aluminium
- Easy changing of the saw blade thanks to the spindle lock
- High-grade carbide blade for clean cuts
- Sawblade with 20mm and 30mm bore diameter can be used
- Dust extraction adapter to keep the workplace clean
- Compatible with the Einhell guide rail
- Parallel stop for precise cuts
- Supplied without battery and charger (available separately)

Technical Data

3800 min^-1 - No-load speed Ø190 x Ø20 mm - Saw Blade - Number of saw teeth 24 Pieces - Cutting depth at 90° 65 mm - Cutting depth at 45° 45 mm

Logistic Data

- Product weight 3.23 kg - Gross weight single packaging 4.52 kg

380 x 230 x 320 mm - Dimensions single packaging

- Pieces per export carton 2 Pieces - Gross weight export carton 9.41 kg

- Dimensions export carton 475 x 395 x 340 mm - Container quantity (20"/40"/40"HC) 846 | 1756 | 2132





















Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019

Einhell Accessory



18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396

Bar Code: 4006825610376

Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729

Einhell Accessory

18V 4,0Ah PXC Starter Kit 2 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437

Bar Code: 4006825616606

Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341

Bar Code: 4006825590593 **Einhell Accessory**



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory

Battery-Running-Times

One Battery for All	sawing ¹
	(m)
1.5 Ah	18
2.0 Ah	24
2.5 Ah	30
3.0 Ah	37
4.0 Ah	49
5.2 Ah	63
6.0 Ah	73

For best performance select a battery with at least 2.5 Ah

Test setup: