



# Einhell

## CLASSIC



**Cordless Hedge Trimmer**

**GC-CH 18/40 Li Solo**

**Item No.: 3410940**

Ident No.: 21011

Bar Code: 4006825661125

The Einhell GC-CH 18/40 Li Solo cordless hedge trimmer is a small, light and handy hedge trimmer from the Power X-Change series. The robust metal gearing is designed for a long service life and caters for perfect delivery of the cordless power to the laser-cut and diamond-ground steel blades. A two-hand safety switch protects the user during operation. This product comes with an aluminium cover for the cutters, an impact guard with holder for wall mounting, and a sturdy bag for storage and transport. One 18V battery from the flexible Power X-Change series is needed to operate the cordless hedge trimmer. This product comes without a battery or charger.

## Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Small and easy to handle
- Low weight for user-friendly operation
- Blades made of laser-cut and diamond-ground steel
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)



## Technical Data

- |                         |                        |
|-------------------------|------------------------|
| - Blade length          | 475 mm                 |
| - Cutting length        | 400 mm                 |
| - Spacing between teeth | 13 mm                  |
| - Cuts per minute       | 2400 min <sup>-1</sup> |

## Logistic Data

- |                                      |                    |
|--------------------------------------|--------------------|
| - Product weight                     | 2 kg               |
| - Gross weight single packaging      | 2.55 kg            |
| - Dimensions single packaging        | 865 x 205 x 163 mm |
| - Pieces per export carton           | 4 Pieces           |
| - Gross weight export carton         | 12.76 kg           |
| - Dimensions Export Carton           | 870 x 425 x 245 mm |
| - Container quantity (20"/40"/40"HC) | 1152   2412   2680 |



## Available as special accessories



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



2x 5,2Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



Maintenance spray  
Hedge Trimmer Accessory  
Item No.: 3403099  
Bar Code: 4006825654608  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 2  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



2x 4,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



2x 3,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512083  
Bar Code: 4006825638509  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



12V 2,0Ah Li-Battery  
Battery  
Item No.: 4511472  
Bar Code: 4006825634655  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB  
Battery  
Item No.: 4511524  
Bar Code: 4006825656206  
Einhell Accessory



5,2Ah & 4A Fastcharger  
PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 2  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



18V 4,0Ah Power X-Change 2  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory

# Battery-Running-Times



cutting<sup>1</sup>  
(min.)

| One Battery for All |     |
|---------------------|-----|
| 1.5 Ah              | 40  |
| 2.0 Ah              | 53  |
| 2.5 Ah              | 67  |
| 3.0 Ah              | 80  |
| 4.0 Ah              | 106 |
| 5.2 Ah              | 139 |
| 6.0 Ah              | 160 |

Test setup:

1) -