







**Cordless Hedge Trimmer** 

GC-CH 1846 Li-Solo

Item No.: 3410642

Ident No.: 21041

Bar Code: 4006825588293

The GE-CH 1846 Li cordless hedge trimmer is an efficient tool which thanks to its low weight and handy size provides good service for the trimming of hedges, shrubs and bushes on large grounds and allotments where there is no connection to the electric power grid. For a long service life the gearing is made of metal, for clean cutting results the blades are made of laser-cut and diamond-ground steel.

## Features & Benefits

- Member of the Power X-Change family, 1x18V battery necessary
- Small and easy to handle
- Low weight for user-friendly operation
- Metal gearing for a long life
- Two-hand safety switch
- Aluminum cover over cutters
- Shock guard with holder for wall mount
- Blades made of laser-cut and diamond-ground steel
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)



## **Technical Data**

- Blade length 520 mm - Cutting length 460 mm 15 mm - Spacing between teeth 2200 min^-1 - Cuts per minute



- Product weight 2 kg - Gross weight single packaging 2.84 kg

892 x 180 x 185 mm - Dimensions single packaging

- Pieces per export carton 4 Pieces - Gross weight export carton 11.36 kg

915 x 375 x 265 mm - Dimensions Export Carton - Container quantity (20"/40"/40"HC) 1152 | 2400 | 3000

















## Available as special accessories



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369

Power X-Twincharger 3A

Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437

Charger Item No.: 4512069

Bar Code: 4006825629729

Einhell Accessory



18V 4,0Ah PXC Starter Kit 2 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory

Bar Code: 4006825616606

**Einhell Accessory** 



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 **Einhell Accessory** 



18V 4,0Ah Power X-Change 2 Battery Item No.: 4511396

18V 3,0 Ah Power-X-Change 2 Battery Item No.: 4511341

Bar Code: 4006825610376 Einhell Accessory

Bar Code: 4006825590593 Einhell Accessory

	<b></b> €
One Battery for All	running time <sup>1</sup>
<u>•</u>	(min.)
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240

**Battery-Running-Times** 

Test setup:

1) -