







#### GE-HH 18/45 Li T-Solo

Item No.: 3410866

Ident No.: 21021

Bar Code: 4006825630602

POWER -CHANGE

The rechargeable high-hedge trimmer GE-HH 18/45 Li T is a very powerful device supporting you at power network-independent maintenance of hedges, shrubs and bushes on large plots and in allotment gardens. The metal gearbox provides long duration, and the knives made of laser-cut and diamond-grind steel provide clean cutting results. Because of their versatile settings, this shrub shears can be adjusted to each working situation quickly and simply. Battery and charger are not included in delivery.

### **Features & Benefits**

- Member of the Power X-Change family, 1x18V batteries necessary
- Main handle tiltable by 4 settings
- Motor head tiltable by 7 settings
- Continuously adjustable telescopic aluminum handle
- Additional adjustable handle with quick fastener
- Metal gearing for a long life
- Blade made of laser-cut and diamond grinded steel
- Sturdy cutter guard for storage and transportation
- Carrying belt
- Supplied without battery and charger (available separately)

### **Technical Data**

Blade length
Max. cutting length
Spacing between teeth
Cuts per minute
450 mm
400 mm
16 mm
700 min^-1

## **Logistic Data**

- Product weight (kg) 4.28 - Gross weight (kg) 5.44

- Dimensions single packaging 205 x 122 x 1215 mm

- Pieces per export carton 3 Pieces- Gross weight of export carton 17.5 kg

Dimensioins export carton
 Container quantity (20"/40"/40"HC)
 1230 x 370 x 245 mm
 750 | 1551 | 1701





















# Available as special accessories



Pruner Unit f. GE-HH18/45Li T Multifunctional Tool-GT Acces. Item No.: 3410835 Bar Code: 4006825624656 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395

Bar Code: 4006825610369 **Einhell Accessory** 



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 **Einhell Accessory** 



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



18V 3,0 Ah Power-X-Change 2 Battery Item No.: 4511341

Bar Code: 4006825590593 Einhell Accessory



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



18V 4,0Ah PXC Starter Kit 2 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 **Einhell Accessory** 



18V 4,0Ah Power X-Change 2 Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory

## **Battery-Running-Times**

One Battery for All	running time1	
	(min.)	
1.5 Ah	20	
2.0 Ah	30	
2.5 Ah	35	
3.0 Ah	40	
4.0 Ah	60	
5.2 Ah	75	
6.0 Ah	80	

Test setup:

1) -