Einhell

EXPERT

POWER X-CHANGE

Cordless Lawn Mower

GE-CM 18/30 Li (1x3,0Ah)

Item No.: 3413155

Ident No.: 21031

Bar Code: 4006825629163

The Einhell GE-CM 18/30 Li cordless lawn mower is a powerful helper for maintaining lawns. Recommended for lawn areas up to 150m². The rechargeable battery from the Power X-Change family can be used in all the devices from the system series. Three LEDs show the charge status at a glance. For a long service life the mower has an Einhell brushless motor and a high-quality impact-resistant plastic housing. Practical features include the folding long handle for compact storage, the integrated carry handle for easy transportation and the 3-level axial cutting height adjustment facility. Large wheels exert less stress on the lawn. The product is supplied with a rechargeable battery and a system charger.

Features & Benefits

- Brushless motor - more power and prolonged operation
- Axial cutting height adjustment, 3 levels
- Long handle folding - space saving storage
- Integrated carry-handle for easy transport
- Grass protecting, large wheels
- High quality, blow tough plastic housing
- Recommended for lawn areas up to 150 m²
- Supplied with 1x 3,0Ah battery and 1x high-speed charger

Technical Data

- Accumulator	18 V | 3000 mAh | Li-Ion
- Charging time	1h
- Idle speed	3300 min^-1
- Cutting width	30 cm
- Cutting height adjustment	3 | 30-70 mm | axial wheel
- Capacity of catching device	25 L
- Wheel diameter front	140 mm
- Wheel diameter rear	140 mm

Logistic Data

- Gross weight (kg)	11.55
- Product weight (kg)	9.32
- Dimensions single packaging	605 x 395 x 375 mm
- Pieces per export carton	1 Pieces
- Gross weight export carton	11.55 kg
- Dimensions export carton	605 x 395 x 375 mm
- Container quantity (20"/40"/40"HC)	312 | 642 | 749

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Available as special accessories

Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory

2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

12V 2,0Ah Li-Battery
Battery
Item No.: 4511472
Bar Code: 4006825634655
Einhell Accessory

18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory

18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory

5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory

18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory

18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Spare Blade GE-CM 18/30 Li
Lawn Mower Accessory
Item No.: 3404553
Bar Code: 4006825633092
Einhell Accessory

18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory

18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

2x 4,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory

18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Battery-Running-Times

One Battery for All	lawn mowing[1] (m²)
1.5 Ah	30
2.0 Ah	70
2.5 Ah	100
3.0 Ah	150
4.0 Ah	210
5.2 Ah	270
6.0 Ah	300

For best performance select a battery with at least 3.0 Ah

Test setup:

1) -

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory