Einhell

CLASSIC

POWER X-CHANGE

Cordless Hedge Trimmer

GC-CH 1855/1 Li Kit (1x2,5 Ah)

Item No.: 3410506

Ident No.: 21031

Bar Code: 4006825661910

The GC-CH 1855/1 Li Kit cordless hedge trimmer is a very efficient tool which provides good service for the trimming of hedges, shrubs and bushes on large grounds where there is no connection to the electric power grid. With the Power X-Change battery system from Einhell, the hedge trimmer has an 18 V battery pack with 2.5 Ah for long work sessions. For a long service life the gearing is made of metal, for clean cutting results the blades are made of laser-cut and diamond-ground steel.

Features & Benefits

- Member of the Power X-Change family
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- System high-speed charger included
- Blades made of laser-cut and diamond-ground steel
- Adjustable additional handle
- Swivel handle
- Handy
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover on cutters
- Bumper guard with holder for wall mount
- Cutting collector
- Sturdy cutter guard for storage and transportation
- Supplied with 2,5Ah battery and high-speed charger





















Technical Data

- Cutting length	550 mm
- Blade length	620 mm
- Spacing between teeth	18 mm
- Cuts per minute	2200 min^-1
- Accumulator	18 V | 2500 mAh | Li-Ion
- Number of accumulators	1 Pieces

Logistic Data

- Product weight	2.6 kg
- Gross weight single packaging	3.7 kg
- Dimensions single packaging	1005 x 130 x 170 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	14.8 kg
- Dimensions Export Carton	1040 x 290 x 275 mm
- Container quantity (20"/40"/40"HC)	1344 | 2880 | 3240

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory
Generated at: 01.02.2022 09:07

Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



12V 2,0Ah Li-Battery
Battery
Item No.: 4511472
Bar Code: 4006825634655
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Battery-Running-Times

One Battery for All	running time[1] (min.)
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240

Test setup:

1) -

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory