







GE-ST 36/40 Li E-Solo

Item No.: 3417011

Ident No.: 21022

Bar Code: 4006825659979

OWER X-CHANGE

The Einhell GE-ST 36/40 Li E-Solo cordless snowblower is a powerful member of the Power X-Change family, equipped with TWIN PACK technology and driven by a brushless motor, individually adjustable by the speed control. The snow ejection direction can be individually set to left, right or straight ahead. The additional handle allows a pleasant two-hand operation and stable guidance. A carrying handle is integrated on the self-supporting snowblower. The 2-point safety switch protects against accidental starting, while the battery cover with magnetic closure protects against snow and moisture. 2x 18V batteries are required for operation, optimally 4.0 Ah or larger. Delivery does not include battery or charger.

## Features & Benefits

- Member of the Power-X-Change family, 2x18V battery necessary
- TWIN-PACK technology: 2x18V Power-X-Change batteries more power
- Brushless motor more power and longer running time
- Snow ejection direction adjustable: left, right or straight ahead
- Speed control, suitable for snow conditions
- Battery cover with magnetic closure saves from snow and water
- Additional handle enables a comfortable two-hand-operation
- Integrated transport handle for easy transport
- Ergonomic handle with softgrip
- Self-standing
- Two-point safety switch protects from accidental start
- Recommendation for optimum results: 4,0 Ah battery & higher
- Supplied without battery and charger (available separately)

## **Technical Data**

- Max. snow height 20 cm - Max. working width 40 cm - Max. throwing distance 6 m

## **Logistic Data**

- Product weight (kg) 6.41 - Gross weight (kg) 8.81 - Pieces per export carton 1 Pieces - Gross weight of export carton 8.81 kg

- Dimensions export carton 580 x 350 x 390 mm - Container quantities (20"/40"/40"HC) 360 | 730 | 860

















**BEST** WITH ≥ 4.0 Ah



## Available as special accessories



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory



18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory



PXC Akku-Wandhalterung Case Item No.: 4514155 Bar Code: 4006825658774 Einhell Accessory



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery Item No.: 4511600 Bar Code: 4006825665055 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB Battery Item No.: 4511524 Bar Code: 4006825656206 Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit Item No.: 4512114 Bar Code: 4006825656787 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory