







Cordless Vacuum Cleaner

TE-VC 18 Li-Solo

Item No.: 2347120

Ident No.: 21031

Bar Code: 4006825612646

The Einhell TE-VC 18 Li-Solo cordless hand vacuum cleaner is a convenient powerhouse of the Power X-Change family. The same rechargeable battery can be used in all PXC devices. Every surface and crevice can be thoroughly cleaned thanks to the individual nozzles. The floor nozzle is suitable for smooth surfaces. A second nozzle is provided for upholstery and fabrics. Hard-to-reach areas can be cleaned effortlessly using the crevice nozzle. Use the 46.5 cm extension tube when you want to clean the floor using the handheld vac as a floor vacuum cleaner. The dust container has a capacity of 540 ml. For space-saving storage there is an integrated wall bracket. The product is supplied without a battery & charger which are available separately.

Features & Benefits

- A member of the Power X-Change family, 1x18V battery necessary
- Dust container with a volume of 540 ml
- Cleaning the filters under running water
- Incl. floor nozzle for hard floors and smooth surfaces
- Incl. crevice nozzle for hard to reach areas
- Incl. upholstery nozzle for cleaning upholstery and fabrics
- Incl. extension tube (46.5 cm) for cleaning floors
- Space-saving storage thanks to the integrated wall bracket
- Supplied without battery and charger (available separately)

Technical Data

Suction power max.
Suction volume
Volume
Length of suction tube
Diameter of suction tube
Sound pressure level Lpa
42 mbar
0.54 L
46.5 cm
32 mm
68 dB (A)

Logistic Data

- Product weight 0.85

- Dimensions single packaging 472 x 130 x 193 mm

- Pieces per export carton- Gross weight export carton4 Pieces8.2 kg

- Dimensions Export Carton 490 x 290 x 410 mm - Container quantity (20"/40"/40"HC) 1920 | 4000 | 4700

















18 V

42 mbar 540

Available as special accessories



18V 2,0Ah Power X-Change

Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042

Bar Code: 4006825613704

Einhell Accessory



Power X-Twincharger 3A Charger

Item No.: 4512069 Bar Code: 4006825629729

Einhell Accessory



Power X-Boostcharger 6A

Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396

Bar Code: 4006825610376

Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437

Bar Code: 4006825616606 **Einhell Accessory**



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681

Einhell Accessory



18V 3,0 Ah Power-X-Change 2

Battery Item No.: 4511341

Bar Code: 4006825590593 Einhell Accessory

Battery-Running-Times

One Battery for All	vacuuming¹ (min.)
1.5 Ah	12
2.0 Ah	16
2.5 Ah	18
3.0 Ah	23
4.0 Ah	31
5.2 Ah	40
6.0 Ah	46

Test setup:

1) -