
















The following Power X-Change devices fit into the E-Case L:

Item no.		Description	Image
2093233	CE-CP 18/180 Li	Autotechnique Accessory	
4512064	Power X-Boostcharger 6A	Charger	
4512011	Power X-Charger 3A	Charger	
4512069	Power X-Twincharger 3A	Charger	
4512102	Power X-Quattrocharger 4A	Charger	
4512096	Power-X-Charger 18V	Charger	
4512103	Power X-Fastcharger 4A	Charger	
2093320	CE-CP 18/180 Li E	Cl. Polishing/Sanding Machine	
4260025	TC-SY 18/60 Li	Cl.Paint Spray Sys (Spray Gun)	
2070110	CE-AP 18 Li	Cordless Air Pump	
4326300	TE-AP 18 Li	Cordless All Purpose Saw	
4326290	TE-AP 18/26 Li	Cordless All Purpose Saw	
4326310	TE-AP 18/28 Li BL	Cordless All Purpose Saw	
4431140	AXXIO	Cordless Angle Grinder	

4431150	AXXIO 18/115 Q	Cordless Angle Grinder	
4431151	AXXIO 18/125 Q	Cordless Angle Grinder	
4431130	TC-AG 18/115 Li	Cordless Angle Grinder	
4431110	TE-AG 18/115 Li	Cordless Angle Grinder	
4431165	TE-AG 18/115 Q Li	Cordless Angle Grinder	
4431144	TE-AG 18/150 Li BL	Cordless Angle Grinder	
4466270	TP-BS 18/457 Li BL	Cordless Belt Sander	
4350630	TE-BJ 18 Li	Cordless Biscuit Jointer	
3408001	TE-CB 18/180 Li	Cordless Blower	
2071010	CE-CC 18 Li	Cordless Car Air Compressor	
2093301	CE-CB 18/254 Li	Cordless Car Polisher	
4501760	GE-LC 18/25 Li	Cordless Chain Saw	
4499940	GE-CS 18 Li	Cordless Chain Sharpener	
4331220	TE-CS 18/150 Li	Cordless Circular Saw	
4331207	TE-CS 18/165-1 Li	Cordless Circular Saw	

4331210	TE-CS 18/190 Li BL	Cordless Circular Saw	
4514160	TE-DA 18/760 Li	Cordless Drain Cleaner	
4513927	TC-CD 18/35 Li	Cordless Drill	
4513692	TE-CD 18 Li	Cordless Drill	
4513850	TE-CD 18 Li BL	Cordless Drill	
4513870	TE-CD 18 Li E	Cordless Drill	
4513925	TE-CD 18/40 Li	Cordless Drill	
4513997	TE-CD 18/40 Li BL	Cordless Drill	
4513887	TE-CD 18/50 Li BL	Cordless Drill	
4514210	TP-CD 18/60 Li BL	Cordless Drill	
4259980	TE-DY 18 Li	Cordless Drywall Screwdriver	
4180400	AQUINNA 36/30	Cordless Garden Pump	
3410370	GE-CG 18 Li	Cordless Grass- and Bush Shear	
3410313	GE-CG 18/100 Li	Cordless Grass- and Bush Shear	
3410310	GE-CG 18/100 Li T	Cordless Grass- and Bush Shear	

3410382	GC-CG 18/1 Li	Cordless Grass Shear	
4513960	TC-ID 18 Li	Cordless Hammer Drill	
4520500	TE-HA 18 Li	Cordless Hot Air Gun	
4522200	TE-CG 18 Li	Cordless Hot Glue Gun	
4513860	TE-CD 18 Li-i BL	Cordless Impact Drill	
4513926	TE-CD 18/48 Li-i	Cordless Impact Drill	
4513942	TE-CD 18/50 Li-i BL	Cordless Impact Drill	
4514205	TP-CD 18/60 Li- i BL	Cordless Impact Drill	
4510080	IMPAXXO 18/230	Cordless Impact Driver	
4510070	IMPAXXO 18/400	Cordless Impact Driver	
4510030	TE-CI 18 Li BL	Cordless Impact Driver	
4510034	TE-CI 18/1 Li	Cordless Impact Driver	
4510040	TE-CW 18 Li BL	Cordless Impact Driver	
4321209	TC-JS 18 Li	Cordless Jig Saw	
4321200	TE-JS 18 Li	Cordless Jig Saw	

4514130	TC-CL 18 Li H	Cordless Light	
4514115	TC-CL 18/1800 Li	Cordless Light	
4514110	TE-CL 18 Li	Cordless Light	
4514114	TE-CL 18/2000 LiAC	Cordless Light	
4514145	TE-CL 18/2500 LiAC	Cordless Light	
4331100	TE-CS 18/89 Li	Cordless Mini Circular Saw	
4465170	TC-MG 18 Li	Cordless Multifunctional Tool	
4465160	VARRITO	Cordless Multifunctional Tool	
4460713	TE-OS 18/1 Li	Cordless Multiple Sander	
4460708	TE-OS 18/150 Li	Cordless Multiple Sander	
4257790	TE-CN 18 Li	Cordless Nailer	
4460725	TC-OS 18/187 Li	Cordless Orbital Sander	
4460720	TE-OS 18/230 Li	Cordless Orbital Sander	
4258760	TE-MX 18 Li	Cordless Paint/Mortar Mixer	
4345400	TE-PL 18/82 Li	Cordless Planer	

3408220	GE-GS 18 Li	Cordless Pruning Saw	
3408300	GE-LS 18 Li	Cordless Pruning Shears	
3408017	TC-RA 18 Li BT	Cordless Radio	
3408015	TE-CR 18 Li	Cordless Radio	
3407980	TE-CR 18 Li DAB+/FM/BT	Cordless Radio	
4513900	HEROCCO	Cordless Rotary Hammer	
4513812	TE-HD 18 Li	Cordless Rotary Hammer	
4513970	TE-HD 18/12 Li	Cordless Rotary Hammer	
4462010	TE-RS 18 Li	Cordless Rotating Sander	
4350410	TP-RO 18 Set Li BL	Cordless Router / Palm Router	
4522250	TE-SG 18/28 Li	Cordless Sealing Gun	
4514150	TC-SR 18 Li BT	Cordless Speaker	
2347120	TE-VC 18 Li	Cordless Vacuum Cleaner	
4020460	PRESSITO	Hybrid-Compressor	
4600020	FORTEXXA 18/20 TH	Top-handled Cordless Chain Saw	

4514120	TC-CP 18 Li USB	USB Power Bank	
---------	-----------------	----------------	---