



Einhell

EXPERT

POWER X-CHANGE

Cordless Hedge Trimmer

GE-CH 36/61 Li-Solo

Item No.: 3410965

Ident No.: 21011

Bar Code: 4006825662382

The Einhell cordless hedge trimmer GE-CH 36/61 Li-Solo will help make the most of your garden – without cables and right into the tightest corners. As part of the PXC family, the batteries can be used in over 200 Einhell devices. The unit needs 2x 18 V batteries to run. The blades made of laser-cut and diamond-ground steel offer durability, as does the metal gearing. The ergonomic narrow front handle with micro-switch makes for comfortable working. It is equipped with a cuttings collector, an aluminum blade cover, and an impact guard with holder for wall mounting. The sturdy cutter guard enables safe transportation and storage. This product comes without a battery or charger. These are available separately, for example as a starter set.

Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Blades made of laser-cut and diamond-ground steel
- Ergonomic, small front handle with micro switches
- Metal gearing for a long life
- Cutting collector
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)




Technical Data

- Cutting length 610 mm
- Blade length 670 mm
- Spacing between teeth 26 mm
- Cuts per minute 2400 min⁻¹

Logistic Data

- Product weight 2.8 kg
- Gross weight single packaging 4.25 kg
- Dimensions single packaging 1100 x 233 x 148 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 18.5 kg
- Dimensions Export Carton 1110 x 475 x 225 mm
- Container quantity (20"/40"/40"HC) 864 | 1728 | 2112



Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times



One Battery for All	running time ¹⁾ (min.)
1.5 Ah	54
2.0 Ah	72
2.5 Ah	80
3.0 Ah	105
4.0 Ah	144
5.2 Ah	168
6.0 Ah	210
8.0 Ah	288

Test setup:

1) -